

Keysight X-Series Signal Analyzers

This manual provides documentation for the following instruments:

UXA Signal Analyzer N9040B

PXA Signal Analyzer N9030A/B

MXA Signal Analyzer N9020A/B

EXA Signal Analyzer N9010A/B

CXA Signal Analyzer N9000A/B

MXE EMI Receiver N9038A

NFA Noise Figure Analyzer N8973B-N8976B

Instrument
Messages

Notices

Copyright Notice

© Keysight Technologies 2008-2016

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Manual Part Number

N9020-90095

Edition

Edition: 3, September 2016

Supersedes: June 2016

Published by:

Keysight Technologies Inc.
1400 Fountaingrove Parkway
Santa Rosa, CA 95403

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

U.S. Government Rights

The Software is “commercial computer software,” as defined by Federal Acquisition Regulation (“FAR”) 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement (“DFARS”) 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at

<http://www.keysight.com/find/sweula>

The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED “AS IS,” AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED, WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR OF ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT SHALL CONTROL.

Safety Information

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

Where to Find the Latest Information

Documentation is updated periodically. For the latest information about these products, including instrument software upgrades, application information, and product information, see the following URLs:

<http://www.keysight.com/find/uxa>

<http://www.keysight.com/find/pxa>

<http://www.keysight.com/find/mxa>

<http://www.keysight.com/find/exa>

<http://www.keysight.com/find/cxa>

<http://www.keysight.com/find/mxe>

<http://www.keysight.com/find/nfa>

To receive the latest updates by email, subscribe to Keysight Email Updates:

<http://www.keysight.com/find/emailupdates>

Information on preventing instrument damage can be found at:

<http://www.keysight.com/find/PreventingInstrumentRepair>

Is your product software up-to-date?

Periodically, Keysight releases software updates to fix known defects and incorporate product enhancements. To search for software updates for your product, go to the Keysight Technical Support website at:

<http://www.keysight.com/find/techsupport>

Table of Contents

List of Instrument Messages 6	
1 Overview of Instrument Messaging System	23
A-Series and B-Series Differences	23
Message Types	23
Event and Condition Categories	25
Event Categories	26
Condition Categories	27
Error Message Fields	28
Event Queues & Displays	29
Message Display & Controls	31
A-Series	31
B-Series	31
Event Message Boxes	31
Status Bar	33
Status Dialog	33
2 Instrument Messages	34
Advisory Messages	35
Event Messages	41
-800, Operation Complete Event	42
-700, Request Control Event	42
-600, User Request Event	42
-500, Power on Event	42
-400 to -499, Query Errors	42
-300 to -399, Device-Specific Errors	44
-221 Settings Conflict Errors	46
-200 to -299, Execution Errors	63
-100 to -199, Command Errors	79
0 No Error	81
Condition Messages	82
1 to 99, Calibration	82
6 to 34, Calibration Skipped	82
36 to 64, Calibration Needed or Failed	83
65 to 92, Calibration Needed (Extended)	85
67 to 95, Calibration Failure (Extended)	86
101 to 199, Measurement Integrity	87
201 to 299, Signal Integrity	92

301 to 399, Uncalibrated Integrity	97
401 to 499, Power	100
501 to 599, Frequency	101
601 to 699, Error Summaries	102
701 to 799, Operation	104
801 to 899, Temperature	105
3 Status Register System & SCPI STATUS Subsystem	107
Where to find Detailed Information	107
Status Register System Overview	108
Appendix A References	111
Documents & Web Sites	111

List of Instrument Messages

This list includes every Instrument Message described in this document, in alphabetical order.

2nd LO Unlocked	101	
AC coupled: Accy unspec'd <10 MHz	97	
ADC Alignment Failure	84	
Align 30MHz to 1GHz failed	87	
Align 30MHz-1GHz required	85	
Align 9kHz to 30MHz failed	87	
Align 9kHz-30MHz required	85	
Align Now, All required	85	
Align Now, RF required	85	
Align RF Skipped	83	
Align Skipped Sum Summary	85	
Align Source IQ failed	87	
Align Source RF failed	87	
All Auto/Man functions have been set to Auto	35	
All ranges are off. Turn on at least a range	64	
Allowable Center Frequency exceeded for the current span	35	
Allowable Span exceeded for the current center frequency	35	
Allowable Start Frequency exceeded for the current span	35	
Allowable Stop frequency exceeded for the current span	35	
Already in Single, press Restart to initiate a new sweep or sequence	35	
Antenna Unit already in used in another range	74	
Arm deadlock	67	
Arm ignored	66	
At Full Zoom	64	
Auto sweep time rules do not apply in FFT sweeps	35	
Band Adjust has no effect on a Fixed marker	35	
Band Adjust has no effect with Mkr Function Off	35	
Band-pass filter set to OFF	35	
Block data error	80	
Block data not allowed	80	
Burst Not Found	93	
Burst not found; with selected Time Slot	94	
Cal Cancelled; Calibration data cleared	35	
Cal Invalid: meas freq pt(s) > 3.6GHz are > 50MHz from existing Cal pts	36	
Calibrating	104	
Calibration failed; <failure msg><port>	45	
Calibration memory lost	45	

List of Instrument Messages

Calibration Oscillator Unlocked	102
Calibration	103
Calibration	99
Calibration; ENR table extrapolated	99
Calibration; No ENR data present	99
Cannot create program	77
Cannot move marker outside of displayed frequency span	64
Carrier power is too low for optimum dynamic range.	36
Carrier(s) incorrect or missing	94
Character data error	80
Character data not allowed	80
Character data too long	80
Characterize Noise Floor required	86
Characterize Preselector failure	87
Characterize Preselector required	86
Command error	79
Command header error	79
Command protected	66
Command protected; feature not licensed	66
Command protected; Feature Not Supported. No appropriate waveform license installed for <filename>	66
Communication error	45
Communication error; SNS data read failure. Disconnect then reconnect SNS	45
Communication error; SNS is not connected	45
Configuration memory lost	45
Connecting to source...	36
Correction Group range data	69
Corrupt media	76
Data corrupt or stale; Measurement data is not available	72
Data corrupt or stale; Trace contains no data.	72
Data corrupt or stale; Unable to load state from file	72
Data corrupt or stale;	72
Data out of Range; clipped to source max/min	69
Data out of Range; Dwell Time clipped to minimum value allowed	69
Data out of range; Invalid list data	69
Data out of range; Invalid	69
Data out of Range; Scan Time limited, multiple CISPR det's in use for prescan	69
Data out of Range; Step Size clipped to nearest value allowed	69
Data out of range; Two entries already exist at this x-axis value.	69
Data out of range;	69
Data questionable	72
Data type error	79
DC Coupled	104

De-emphasis only available in FM	46
Demod Error	95
Demod Error; Acq Time too short	96
Demod Error; Can't correlate	95
Demod Error; Data interval too short	96
Demod Error; Muxed bits not found	96
Demod Error; No active channel	96
Demod Error; No full subframe found	96
Demod Error; Not an active slot	96
Demod Time is not available in Zero Span	36
Demodulation	102
Detector <X> changed due to physical constraints	36
Device-specific error	44
Directory full	76
Disturbance List is Empty	64
Disturbance selected is not in the Disturbance List	64
Dynamic range is not optimum. Set AUTO RF input.	36
Execution Error	64
Execution error; Carrier frequency outside device's transmit band	64
Execution Error; Correction File Range x File x frequency out of range	64
Execution error; Invalid GSM burst timing	64
Execution error; Invalid IP address	64
Execution error; Invalid Marker Trace.	64
Execution Error; No peak found.	64
Execution error; No ranges are defined. Activate a range.	65
Execution Error; Preselector centering failed	65
Execution Error; Signal not stable enough to track	65
Execution Error; Store ref trace before turning on Normalize	65
Execution error; Sync word was not found.	65
Execution error; Trace file contains no compatible traces.	65
Execution error; Trace file created by incompatible version of Phase Noise App	65
Exp. Averaging not available when AUTO PhNoise is active.	36
Exponent too large	79
Expression data not allowed	80
Expression error	77
Expression error	80
Extended Align Failure Summary	85
Extended Align Needed Summary	85
FFT Width is not settable unless Sweep Type is set to FFT	36
File <filename> saved	36
File name error; <filename> contains unrecognized file suffix	77
File name error; Allowable extension is .csv	76
File name error; Allowable extension is .png	76

List of Instrument Messages

File name error; Allowable extension is .state	76
File name error; Invalid file name	77
File name error; name too long	77
File name error; Waveform file not selected	77
File name error;	76
File name not found: <file name>	76
File name not found;	76
Filter BW function is only available for Gaussian filter type	36
Fixed LO freq should be greater than RF Stop freq	36
FM Demod Alignment Failure	84
Framing error in program message	46
Freq Out of Range	94
Freq Out of Range; External LO	94
Freq Out of Range; System input (IF)	94
Freq Scale Type=Log is not available in Zero Span	36
Frequency Hopping enabled, waiting for valid burst	36
Frequency menu has changed to reflect frequency context switch	37
Frequency Reference Unlocked	101
Frequency	103
Function not available before Marker Zoom is performed	65
Function not available before perform Disturbance Zoom	65
Function not available before Signal Zoom is performed	65
Function not available in Zero Span	46
Gate required for valid results	37
GET not allowed	79
Hardware error	73
Hardware error; See details in Windows Event Log under SA	73
Hardware missing	73
Hardware missing; Input not available	73
Hardware missing; Internal preamp not available at all frequency points	73
Hardware missing; not available for this model number	73
Hardware missing; Option not installed	73
Header separator error	79
Header suffix out of range	79
High-pass and Low-pass filters set to OFF	37
High-pass filter set to OFF	37
I/O Error	90
I/O Error; Ext Source needs IP Addr	90
IF Alignment Failure	84
IF Fixed freq should be greater than LO Stop freq	37
IF Fixed freq should be greater than RF Stop freq	37
IF Start freq should be greater than LO Fixed freq	37
IF Start freq should be greater than RF Start freq	37

IF Synthesizer Unlocked	101
Illegal macro label	77
Illegal parameter value	70
Illegal parameter value; <Value> invalid. Fractional values are not allowed.	70
Illegal parameter value; <value> out of range.	70
Illegal parameter value; Cannot set waveform to continue previous waveform on the first step	70
Illegal parameter value; Cannot set waveform to continue previous waveform when previous step is set to CW or Off	71
Illegal parameter value; Channel number is invalid for current band/link combination	71
Illegal parameter value; Exceeding the max list length	70
Illegal parameter value; existing Screen Name not found	70
Illegal parameter value; Gated FFT is not available while Sweep Type is set to Swept	70
Illegal parameter value; Gated LO is not available while Sweep Type is set to FFT	70
Illegal parameter value; Gated Video is not available while Sweep Type is set to FFT	70
Illegal parameter value; Index out of range	71
Illegal parameter value; Invalid list length	71
Illegal parameter value; Measurement not available	71
Illegal parameter value; new Name already exists	71
Illegal parameter value; Res BW value not allowed with current Span	71
Illegal parameter value; This instrument is always DC coupled	71
Illegal parameter value; This model is always AC coupled	71
Illegal program name	78
Illegal variable name	78
Incompatible type	78
Init ignored	66
Input Attenuation not calibrated	86
Input buffer overrun	46
Input is internal	37
Input Overload	89
Input Overload; ADC over range	89
Input Overload; I/Q ADC over range	89
Input Overload; I/Q Voltage over range	89
Input Overload; RF Preselector Overload	89
Insufficient Data	89
Insufficient Data; ENR table empty	89
Insufficient Data; frequency list empty	89
Insufficient Data; Incr. Demod Time	89
Insufficient Data; Loss table empty	89
Integrity	103
Invalid block data	80
Invalid character data	80
Invalid character in number	79

Invalid character	79
Invalid Data	90
Invalid expression	80
Invalid format	72
Invalid format; <filename> contains invalid waveform header and cannot be loaded into ARB memory	72
Invalid format; <filename> has less than 500 IQ samples	72
Invalid format; Map information not loaded	72
Invalid format; Syntax error on source step <step number>	72
Invalid format; Unable to open encrypted waveform file <filename>	72
Invalid inside macro definition	81
Invalid outside macro definition	80
Invalid separator	79
Invalid string data	80
Invalid suffix	80
Invalid version	72
Invalid while in local	66
List not same length	72
LO Alignment Failure	84
LO Fixed freq should be greater than IF Stop freq	37
LO Fixed freq should be greater than RF Stop freq	37
LO Start freq should be greater than IF Fixed freq	38
LO Start freq should be greater than RF Start freq	38
LO Stop freq should be greater than RF Stop freq	38
LO Unleveled	100
LO Unlocked	101
Low-pass filter set to OFF	38
Macro definition too long	77
Macro error	77
Macro error	80
Macro execution error	77
Macro header not found	77
Macro parameter error	77
Macro parameter error	81
Macro recursion error	77
Macro redefinition\ not allowed	77
Macro syntax error	77
Mass storage error; <directory> does not exist	75
Mass storage error; <filename> cannot be deleted as it is currently in use	75
Mass storage error; <filename> cannot be deleted as it is used in sequencer	75
Mass storage error; <filename> used by sequencer is not in the ARB memory, cannot start sequencer	75
Mass storage error; Access denied	73

List of Instrument Messages

Mass storage error; Bad path name	73
Mass storage error; Can only import single trace .csv files	73
Mass storage error; Can only load an Antenna Unit into Correction 1	73
Mass storage error; Can only load one file with Antenna Unit per range	73
Mass storage error; Cannot make	73
Mass storage error; Create Directory Error: <directory> <err info>	76
Mass storage error; Delete File Error: <filename> <err info>	76
Mass storage error; Different Antenna Unit already in use	74
Mass storage error; Different	74
Mass storage error; Directory not found	74
Mass storage error; Failed to Load trace. Bad file format.	74
Mass storage error; File <filename> wrong type	74
Mass storage error; File <filename> and instrument version mismatch	74
Mass storage error; File contains incorrect data for this operation	74
Mass storage error; File empty	74
Mass storage error; Invalid register number for *SAV or *RCL Mass Storage error	74
Mass storage error; Lock violation	74
Mass storage error; Mkr Table must be on to save Mkr Table as Meas Results	74
Mass storage error; No file names available	74
Mass storage error; Open failed	75
Mass storage error; Pk Table must be on to save Pk Table as Meas Results	75
Mass storage error; Read fault	75
Mass storage error; Register <number> empty	75
Mass storage error; Sharing violation	75
Mass storage error; Spectrogram must be on to save as Meas Results	75
Mass storage error; Too many open files	75
Mass storage error; Write fault	75
Mass storage error; Write File Error: <filename> <err info>	76
Mass storage error;	73
Math error in expression	77
Meas Error	90
Meas Uncal	97
Measuring	104
Media full	76
Media Full; <filename> cannot be loaded to ARB memory	76
Media Protected	77
Memory error	45
Memory Error	90
Memory Error; Shorten capture interval	90
Memory use errors	78
Missing media	76
Missing parameter	79
MPA Align failed	87

MPA Align required	86
Must perform Scan before do Search	65
No error	81
No Long Code Phase	97
No marked signal	65
No Measure At Marker Added to Signal List	65
No Peak Added to Signal List	66
No Result	88
No Result; Meas invalid with I/Q inputs	88
No Result; Meas/Radio Std incompatibility	88
No Result; Turn on MCE	88
No spurs have been found	38
No unmarked signals	66
Numeric data error	79
Numeric data not allowed	79
Operation complete	42
Operation complete; Loaded <ARB filename> successfully, but no license <required licenses> installed	42
Out of memory	45
Out of memory	71
Out of memory	78
Out of memory; Insufficient resources to load Mode <mode name>	71
Out of memory; Memory limit caused Data Acquisition to be truncated	71
Out of memory; Results truncated	45
Out of memory; Sequence too long	45
Out of memory; Total analysis step reaches its limitation	45
Over current: reboot	105
Over temperature: let cool and reboot	105
Parameter error	67
Parameter error; <filename> does not have a unique id, therefore cannot be assigned to a multi-pack	67
Parameter error; <filename> is not loaded into ARB memory. Load the file before assigning to a multi-pack	67
Parameter error; Cannot create directory to save waveform sequence file. <error info>	67
Parameter error; Cannot find the first waveform file <filename>	67
Parameter error; Invalid waveform sequence file path	67
Parameter error; License slot <n> is already locked	67
Parameter error; License slot <n> is illegal, slot number must be positive	67
Parameter error; License slot <n> is locked and cannot be cleared	67
Parameter error; License slot <n> is locked, therefore cannot be replaced	68
Parameter error; License slot <n> is not assigned, therefore cannot be locked	68
Parameter error; Nested sequence file is not supported	68
Parameter error; Nested sequence file is not supported	68

List of Instrument Messages

Parameter error; No. <n> waveform file path is invalid	68
Parameter error; Repetition value must be within 1 and 65535	68
Parameter error; Sequence will be stuck on step <step number>. Next step trigger cannot be free run when current step duration is continuous	68
Parameter error; Suffix of waveform sequence file should be “.seq”	68
Parameter error; Transition time is longer than duration time on step<step number>	68
Parameter error; Unrecognized marker type: <marker>	68
Parameter error; Waveform <filename> is already assigned to a waveform slot	69
Parameter error; Waveform cannot be multi-pack licensed, no multi-pack slots available	69
Parameter error; Waveform of that ID is already multi-pack licensed	69
Parameter not allowed	79
Parity error in program message	46
Paused	104
Power on	42
Power	103
Preamp: Accy unspec'd <XX kHz	99
Preparing Calculation...	38
Preselector is centered	38
Preselector not used in this frequency range.	38
Probe connected, cal data is being reapplied; <port>; <probe>	38
Probe connected, no probe cal; using cable cal data; <port>; <probe>	38
Probe disconnected, reverting to cable calibration data; <port>	38
Program currently running	78
Program error	77
Program mnemonic too long	79
Program runtime error	78
Program syntax error	78
PUD memory lost	45
Query DEADLOCKED	43
Query Error	42
Query INTERRUPTED	42
Query UNTERMINATED after indefinite response	43
Query UNTERMINATED	42
Queue overflow	45
Reading SNS data...	38
Recalled File <filename>	38
Ref missing or out of range	102
Ref missing or out of range; External	102
Ref missing or out of range; Pulse	102
Refer to online help for assistance with DSB measurements	38
Reference name does not exist; Waveform sequence contains an invalid waveform <filename>	78
Reference Oscillator Oven Cold	105

List of Instrument Messages

Referenced name already exists	78
Referenced name does not exist	78
Request control	42
Requested timeslot number is not present.	38
Res BW changed	39
RF Alignment Failure	84
RF Start freq should be greater than IF Fixed freq	39
RF Start freq should be greater than IF start freq	39
RF Start freq should be greater than LO fixed freq	39
RF Start freq should be greater than LO Start freq	39
RF Stop freq should be greater than IF Stop freq	39
RPP Tripped	100
Save/recall memory lost	45
Scale/Div only applies in Log Y Scale	39
Setting conflict; <trigger source> trigger is not available while input is <input port>	46
Setting conflict; Acquisition # Analysis Step # not exist	46
Setting conflict; Acquisition # not exist.	46
Setting conflict; Acquisition duration time too short, Acq=#	47
Setting conflict; Analysis Interval should be less than ** ms, Acq=# Step=#	47
Setting conflict; Analysis Offset should be greater than # us, Acq=# Step=#	47
Setting conflict; Auto Set RF Level failed, Too much dynamic range is requested	47
Setting conflict; Averaged acquisition duration time exceeds maximum value, Acq=#	47
Setting conflict; Basic Discrete PAVT measurement cannot be averaged, Acq=# Step=#	47
Setting conflict; Basic IQ data measurement cannot be averaged, Acq=# Step=#	47
Setting conflict; Cannot delete current step, minimum number of steps reached	47
Setting conflict; Cannot insert more steps, maximum number of steps reached	47
Setting conflict; Differential setting determined by probe type	47
Setting conflict; DUT Expected Power cannot be greater than Peak Power, Acq=# Step=#	48
Setting conflict; Input Z unavailable when probe sensed	48
Setting conflict; Instrument Gain LOW is not supported when frequency > 3.6 GHz. Auto change it to ZERO, Acq=#	48
Setting conflict; Measurement Bitmap *** not available in Radio Standard ***, Acq=#	48
Setting conflict; PAVT step end time exceeds the analysis interval	48
Setting conflict; PAVT step start time is less than zero	48
Setting conflict; Phase Discontinuity measurement cannot be averaged, Acq=# Step=#	48
Setting conflict; Radio Band *** not available in Radio Standard ***, Acq=#	48
Setting conflict; Radio Device BTS not supported, Acq=#	48
Setting conflict; Radio Standard *** not available, Acq=#	48
Setting conflict; RF Envelope trace is not available without Basic IQ data measurement, Acq=# Step=#	49
Setting conflict; Sequence too long, Acq = #	49
Setting conflict; Transition time may be short on step <step number>.	49
Setting conflict; Transition Time should be greater than # us, Acq=#	49

List of Instrument Messages

Setting conflict; Trigger Delay should be greater than # us, Acq=#	49
Setting conflict; Trigger Level is too low, Acq=#	49
Setting Modified	92
Setting Modified; Filter not applied	92
Settings Alert	90
Settings Alert; Acquisition truncated	91
Settings Alert; Analog Out settings conflict	91
Settings Alert; Diff probe mismatch; < Q ,Q>	90
Settings Alert; Freq>USB Preamp max	92
Settings Alert; I/Q mismatch:<Differential Input Z Attenuation>	91
Settings Alert; LO may overload IF	90
Settings Alert; Parm/data mismatch	91
Settings Alert; Span:RBW Ratio too big	91
Settings Alert; Src pwr ramp>ALC range	91
Settings Alert; Sweep Rate Unavailable	91
Settings Conflict: Timebase DAC not available with Pulse selected	49
Settings conflict; *.CSV file format is not available in this measurement.	49
Settings conflict; <Q Param> cannot be changed when Q same as I	49
Settings conflict; A Valid User Cal is required. Optimize aborted	49
Settings conflict; Administrator privileges required	62
Settings conflict; At least one Phase must be turned on	50
Settings conflict; At least one Protective Earth must be turned on	50
Settings conflict; Auto Scan Time/Meas Time do not apply in Stepped Scan Type.	62
Settings conflict; Auto Tune not available in Tracking Source mode	50
Settings conflict; BTS gain is not available in this Mode	50
Settings conflict; Cal only available when Source Mode is Tracking	50
Settings conflict; Calibration cannot be performed without valid ENR data	50
Settings conflict; Can't Auto-Couple Res BW in Zero Span	50
Settings conflict; Cancellation is not available while measuring DANL floor.	50
Settings conflict; Cancellation Ref trace has no data.	50
Settings Conflict; Cancellation trace has different X-Scale	50
Settings conflict; Cannot accept time or count input when step duration type is Continuous on step #	62
Settings conflict; Cannot optimize while user cal in progress	50
Settings conflict; Carrier freq not allowed with BMT. (Bottom/Middle/Top only)	50
Settings conflict; ClearList & Start not available when ScanSeq = (Re)measure	62
Settings Conflict; Code channel duplication	51
Settings conflict; Cont Mode is not available	51
Settings conflict; Continuous Peak is not available with Fixed marker	51
Settings conflict; Continuous Peak is not available with Signal Track on	51
Settings Conflict; Correction file not specified	51
Settings Conflict; Correction not available with Corr Group on	51
Settings conflict; dB*/MHz is not applicable to the following Y-Axis units, dBm, W, V, A	51

List of Instrument Messages

Settings conflict; Destination trace for Trace Math cannot be a trace operand	51
Settings conflict; Downconv only available when DUT is Amplifier	51
Settings conflict; EDGE EVM only supports EDGE TCH burst type.	51
Settings conflict; Electronic attenuator is disabled	51
Settings conflict; Electronic attenuator is not available above 3.6 GHz	51
Settings conflict; Electronic attenuator unavailable in current state	52
Settings conflict; Electronic attenuator unavailable with Preamp on	52
Settings conflict; EMI Avg/RMS Avg and Average detector can't be used together	52
Settings conflict; EMI Detectors are not available in FFT sweep	52
Settings conflict; Enabled modulation source conflicts with previous modulation source. Previous modulation disabled	52
Settings conflict; External Mixer not available	52
Settings Conflict; FAST method can only be used while Radio Std is W-CDMA	52
Settings conflict; Feature not available for Option <abc>	52
Settings conflict; Feature not available in this View	52
Settings conflict; Feature not supported for selected source	52
Settings conflict; Feature not supported for this Input.	52
Settings conflict; Feature not supported for this measurement.	53
Settings conflict; Feature not supported for this model number	53
Settings conflict; FFT IF Gain High not available when Swept IF Gain = Manual Low	53
Settings conflict; FFT method is unavailable for level gating	53
Settings conflict; FFT sweep type is not available while in Gated LO	53
Settings conflict; FFT sweep type is not available while in Gated Video	53
Settings conflict; FFT Sweeps unavailable in Tracking Source mode	53
Settings conflict; Fixed marker adjust not available while Marker Function is on	53
Settings conflict; Fixed Marker Y value is not adjustable with Normalize On	53
Settings conflict; Freq > 1 GHz is not available while RF Input 2 enabled	62
Settings conflict; Freq > 3.6 GHz unavailable while electronic attenuator enabled	53
Settings Conflict; frequency is outside available range	53
Settings Conflict; Function not available in Correction Trace Display.	53
Settings conflict; Function not available in External Mixing	54
Settings conflict; Function not available in Tracking Source mode	54
Settings conflict; Function not available while measurement is running	62
Settings conflict; Function not available while running multirange scan	54
Settings conflict; Function not available with current LISN Type	54
Settings conflict; Function not available with time domain scan type.	54
Settings conflict; Function only available in Tracking Source mode	54
Settings conflict; Function unavailable with MW Presel off	54
Settings conflict; Function unavailable with this EMC Standard	54
Settings conflict; function unavailable with this EMC Standard	62
Settings conflict; Gate control is Edge for Gated FFT	54
Settings conflict; Gate control must be Edge for this Gate Source	54
Settings conflict; Gate is not available when Marker Count on	54

List of Instrument Messages

Settings conflict; Gate Length is not settable in FFT sweeps	54
Settings conflict; Gate Length is not settable in FFT sweeps	54
Settings conflict; Gate Method is not compatible with current Sweep Type setting	55
Settings conflict; Gate not available with external Tracking Source	55
Settings conflict; Gate not available with Tracking Generator	55
Settings conflict; Gated FFT is not available while Sweep Type is set to Swept	55
Settings conflict; Gated LO is not available while Sweep Type is set to FFT	55
Settings conflict; Gated Video is not available while Sweep Type is set to FFT	55
Settings conflict; Include Source is Yes. ARB memory operation is rejected	62
Settings conflict; Incorrect RBW for demod. Change RBW	55
Settings conflict; Ind I/Q is not available for this measurement	55
Settings conflict; Invalid trace number	55
Settings conflict; Knob is not available to modify this function	55
Settings conflict; Last screen cannot be deleted	62
Settings conflict; Limit cannot be auto-coupled while freq is out of CISPR14 range	55
Settings conflict; LO Phase Noise Adj not available	55
Settings conflict; Log Percent Auto Step Rule does not apply in Swept Scan Type.	62
Settings conflict; Marker 1 Trace Update=off turns off Signal Track	55
Settings conflict; Marker cannot be relative to itself	56
Settings conflict; Marker Count is not available when Gate on	56
Settings conflict; Marker Function is not available for a Fixed marker	56
Settings conflict; Marker type must be delta	56
Settings conflict; Marker-> function is not available in zero span	56
Settings conflict; Mask unavailable for current Span. Increase to display mask.	56
Settings conflict; Meas Type was changed to Examine for Exp Avg Mode.	56
Settings conflict; Meas Type was changed to Full for Repeat Avg Mode	56
Settings Conflict; MinPts/RBW limit not met	56
Settings conflict; Mkr -> CF is not available when the x-axis is time domain	56
Settings conflict; Mod Scheme AutoDet unavailable when Burst Sync=RF Amptd	56
Settings conflict; MPA GPS port power setting <n>dBm is lower than -130dBm minimum	56
Settings conflict; MPA TX port<n> amplitude correction delta exceeds <n>dB between port<n1> and port<n2>	57
Settings conflict; MPA TX port<n> amplitude correction value <n>dB is out of range. The valid range is <n> ~ <n>dB"	57
Settings conflict; MPA TX port<n> power setting <n>dBm is lower than -130dBm minimum	57
Settings conflict; MS gain is not available in this Mode	57
Settings conflict; Multi-Screen requires >1 screen	63
Settings conflict; Must apply Amplitude Correction to make this unit available	57
Settings conflict; No meas frequencies are above 3.6 GHz	57
Settings conflict; no source selected	57
Settings conflict; No Stepped Scan Type	57
Settings conflict; Normalize is not available when Scale Type = Lin	57

List of Instrument Messages

Settings conflict; Normalize is not available while Demod View is on	57
Settings conflict; Normalize is not available while Trace Math is on	57
Settings conflict; Only active Antenna Unit available; no other Y axis units	58
Settings conflict; Option not available	58
Settings conflict; Param only available when DUT is a freq converter	58
Settings conflict; Param only available when External LO Mode is Fixed	58
Settings conflict; Param only available when External LO Mode is Swept	58
Settings conflict; Param only available when Frequency Mode is Fixed	58
Settings conflict; Param only available when Frequency Mode is Swept	58
Settings conflict; Param only available when valid cal data exists	58
Settings conflict; Power search is not available when ALC is On	58
Settings conflict; Power search is not available when RF is Off	58
Settings conflict; Power search is not available when trigger type is not free-run	58
Settings conflict; Preamp gain is not available in this Mode	58
Settings conflict; Preamp unavailable with electronic attenuator on	58
Settings conflict; QPD + EMI Average + RMS Average is not allowed	63
Settings conflict; Range <{0}> is turned off as total range points > 4,000,001	63
Settings conflict; Reference marker must be in same window	59
Settings conflict; Relative Trigger needs hardware support for this meas	59
Settings conflict; Scale Type = Lin is not available when Normalize is on	59
Settings conflict; Scan Time & Points do not apply in current Step/Time Control.	63
Settings conflict; Screen limit reached	63
Settings conflict; Screen SCPI cannot be used when Display is disabled	63
Settings conflict; Sequence may have gaps when playing step <n>, if next step trigger comes later than current step expires	59
Settings conflict; Settings conflict; Pre-trigger is insufficient for demod. Decrease Trig Delay.	59
Settings conflict; Signal Track is not available with Continuous Peak	59
Settings conflict; Signal Track is only available in Swept SA measurement	59
Settings conflict; Signal Track is turned off when Zero Span is selected	59
Settings conflict; Source List Step<n> MPA GPS port power setting <n>dBm is lower than -130dBm minimum	59
Settings conflict; Source List Step<n> MPA TX port<n> amplitude correction delta exceeds <n>dB between port<n1> and port<n2>	60
Settings conflict; Source List Step<n> MPA TX port<n> amplitude correction value <n>dB is out of range. The valid range is <n> ~ <n>dB"	59
Settings conflict; Source List Step<n> MPA TX port<n> power setting <n>dBm is lower than -130dBm minimum	60
Settings Conflict; Span limited to XXX	60
Settings conflict; Span Zoom is not available in Zero Span	60
Settings conflict; Step duration cannot be set to Play Count when the step is generating a CW tone	60
Settings conflict; Step keys are not available to modify this function	60
Settings conflict; Step Size & Meas Time do not apply in current Step/Time Control.	63

List of Instrument Messages

Settings conflict; Sweep Setup only available in swept measurements	60
Settings conflict; Sweep Time cannot be auto-coupled in FFT sweeps	60
Settings conflict; Sweep Time cannot be auto-coupled while in Zero Span	60
Settings conflict; Sweep Time cannot be set while in FFT sweeps	60
Settings conflict; Swept IF Gain High not available when FFT IF Gain = Manual Low	60
Settings conflict; Swept LO not available when freq mode is Fixed	61
Settings conflict; Swept Type=Swept is not available while in Gated FFT	61
Settings conflict; System Display Settings, Annotation is Off	61
Settings conflict; T hot must be greater than T cold	61
Settings conflict; The number of input parameters is too large and is truncated to current list step number	63
Settings Conflict; The parameter cannot be changed in FAST mode	61
Settings conflict; Time Domain Scan is not available with EMC "None" Standard	61
Settings conflict; Too many points; Stop Freq clipped to nearest value allowed	61
Settings conflict; Trace Math is not available while Normalize is on	61
Settings conflict; Tracking Source unavailable in FFT Sweeps	61
Settings conflict; Trigger input in use for source synchronization	61
Settings conflict; Trigger is not available with span > 0 Hz.	61
Settings conflict; Tx Band Spur meas does not support this frequency band.	61
Settings conflict; Tx Band Spur measurement is not defined for mobiles.	62
Settings conflict; X-Scale > 255 MHz unavailable in PVT	62
Settings conflict;	49
Settings conflict;	69
Settings lost due to rtl	66
Settling	104
Signal ID on	97
Signal List is Empty	66
Signal List is Full	66
Signal Selected is not in the Signal List	66
Signal selected is out of display range	66
Signal Summary	88
Signal Too Noisy	96
Signal Track is turned off when Zero Span is selected	39
Signals deleted	39
Slot Error	96
Slot error; No active slot found	96
Slot Error; No idle slot found	96
Source LO Unleveled	100
Source Sweeping	104
Source Synth Unlocked	101
Source Uncal	99
Source Uncal; adj Start Freq or RBW	99
Source Uncal; adjust Source Amplitude	99

Source Unleveled	100	
Source Waiting for Trigger	104	
Storage fault;	45	
String data error	80	
String data not allowed	80	
Suffix error	80	
Suffix not allowed	80	
Suffix too long	80	
Sweep Points/Span is < minimum. Results may be inaccurate.		39
Sweep Setup is not available in Zero Span		39
Sweeping	104	
Sync Error	94	
Sync Error; Midamble sync fail	94	
Sync Error; No freq ref pilot burst	94	
Sync Error; No pilot burst	94	
Sync Error; Preamble length zero	94	
Sync Error; Sync code not found	94	
Sync is RF Ampl (not Training Sequence). Bits are not accurate.		39
Syntax error	79	
System error; <feature> expired, please reboot within <time>		44
System error; <feature> expired, rebooting in <time>		44
System error; A license will soon expire; <feature code> will expire in <time>		44
System Error; enable GPIB controller mode	44	
System error; feature <feature code> not licensed	44	
System error; Feature expired; <feature code>	44	
System error; License installation failed; <feature code>	44	
System error; License removal failed; <feature code>	44	
System error; No license; <feature code> will terminate in <time>		44
System Error; No supported source found	44	
System Error; source connection lost, check interface connection		44
System error;	44	
Temperature	103	
TG Alignment Failure	84	
Time out error	46	
Time out error; Operation on source is held. If analyzer is waiting for trigger, change to free run to proceed	46	
Timing Error: No time ref pilot burst	94	
Timing Error	94	
Too many digits	79	
Too much data	70	
Too much data; 200 spurs found. Additional spurs ignored.		70
Trace file saved.	39	
Trig Error	90	

Trigger deadlock	66
Trigger error	66
Trigger ignored	66
Uncalibrated Summary	89
Undefined header	79
Unexpected number of parameters	79
Use Gate View Sweep Time in the Gate menu.	40
User Cal valid. Apply Cal from Meas Setup menu	40
User cal	97
User Cal; Adjusted for new RBW	99
User Cal; Cal invalidated	98
User Cal; Cal will be interpolated	99
User Cal; Freq outside cal range	99
User request	42
Waiting for Arm	104
Waiting for Trigger	104

1 Overview of Instrument Messaging System

The Error and Status messaging system of the instrument reports events and conditions in a consistent fashion, as well as logging and reporting event history.

This chapter contains the following topics:

- “A-Series and B-Series Differences” on page 23
- “Message Types” on page 23
- “Event and Condition Categories” on page 25
- “Error Message Fields” on page 28
- “Event Queues & Displays” on page 29
- “Message Display & Controls” on page 31

A-Series and B-Series Differences

This guide now covers both "A-Series" and "B-Series" instruments:

- A-Series instruments have part numbers ending in A (for example, N9020A)
- B-Series instruments have part numbers ending in B (for example, N9040B)

The set of messages and the underlying messaging system are common to both A and B-Series. However, the method of displaying messages, and the controls that you can use to interact with the messaging system, differ between A and B-Series. Differences are highlighted below where necessary.

Message Types

Messages may be Events or Conditions:

- An **Event** is simply a message indicating that something has happened. Events are divided according to their severity, into Error, Warning or Advisory categories. These are described in more detail in “Event Categories” on page 26.

The method of displaying messages differs between A-Series and B-Series instruments. For details, see [“Message Display & Controls” on page 31](#).

- A **Condition** is a state of the instrument, which is characterized by a **Detection** (Start) event and a **Clearing** (End) event.

Conditions are divided into two categories: Warnings and Errors. These are described in more detail in [“Condition Categories” on page 27](#).

The method of displaying messages differs between A-Series and B-Series instruments. For details, see [“Message Display & Controls” on page 31](#).

Each Condition’s Start event and End event have numbers and go into the front panel queue. Condition Errors also go into the SCPI queue, but Condition Warnings do not.

All Conditions are mirrored by a bit in the STATus Register Subsystem (see [“Status Register System Overview” on page 108](#)).

Event and Condition Categories

The categories of severity are described below, for both Events and Conditions.

- [Event Categories](#)
- [Condition Categories](#)

Event Categories

Errors

An Event Error occurs when a requested operation is rejected. Generally this means no change is made to the instrument settings. Examples are “Undefined header” or “Peak not found.” Event Errors also occur when an operation is accepted, but fails to complete successfully; for example “Disc full” when attempting to store data.

Error messages are often generated during remote operation when an invalid programming command has been entered.

In some cases, front panel activity generates an Advisory and not an Error event, even though the equivalent SCPI activity generates an Error Event. Typically this is when a function is grayed out; a benign advisory appears on the front panel, because nothing happened, but SCPI must treat it as an error because something that was requested was not delivered.

Event Errors have an associated number, and are sent to both the front panel queue and the SCPI queue for the interface that stimulated the Event.

Warnings

Event Warnings advise you about a potentially unexpected condition that may influence the results of the measurement, for example, if a value is clipped to a different value than that requested.

Another example would be the case where you requested too high a stop frequency, which causes “Data out of range” to be displayed, and the instrument to set itself to the highest available stop frequency.

Event Warnings have an associated number, and are sent to both the front panel queue and the SCPI queue for the interface that stimulated the event.

Advisories

Event Advisories simply provide some useful information. (For example, “File saved successfully” or “Measuring the fundamental”.)

Event Advisories do not have an associated number, and are not reported to SCPI or logged in error queues.

Grayout messages are a special type of Advisory, which appear when you attempt to access a function that is not available. This could be a grayed out front panel key, or an inappropriate SCPI command. There are two types of grayout messages: Benign and Forced.

1. Benign: the requested function is not available because it does not make sense with the current instrument settings. Changing it does not affect the current measurement. (For example, setting the number of FFTs/Span when you are not in the FFT mode.)

A benign grayout gives an Advisory type of message only when the front panel key is pressed.

The requested function cannot be changed from the front panel, but it can be changed remotely.

2. Forced: the requested function is not available either because changing it would cause an invalid measurement, or because of hardware limitations, or because the selection conflicts with other settings. (For example, selecting the electrical attenuator when the frequency span includes frequencies above 3.6 GHz.)

A forced grayout function cannot be changed either from the front panel or remotely. It generates a special type of Advisory message. It also only appears on the front panel when the key is pressed. Remotely, the message will appear in the event queue as a warning “-221, Settings conflict; <conflict description>”.

Condition Categories

Errors

Condition Errors notify you that the instrument cannot make valid measurements while the condition is present.

Examples of error conditions are “LO Unlocked” or “Alignment required”.

A Condition Error exists for a period of time, so it has associated “Detected” and “Cleared” events. (For example, “LO Unlocked” or “External reference out of range”.)

Condition Errors are displayed in the front panel. The Detected and Cleared Events associated with each Condition Error message are logged in the error queues.

Warnings

Condition Warnings appear when a requested operation has completed successfully, but there are modifications and/or side effects.

For example, if you set the sweep time too fast for a measurement to meet the instrument specifications then the “Meas Uncal” message is displayed until you slow down the sweep time.

A Warning Condition exists for a period of time, so it has a “Detected” event and a “Cleared” event.

Condition Warnings are displayed in the front panel, but are not sent to SCPI. They may set status bits in the SCPI Status tree (see [“Status Register System & SCPI STATus Subsystem”](#) on page 107).

Error Message Fields

NOTE

The messages defined for Keysight's instruments extend those specified in the **1999 SCPI Syntax & Style Standard**. As a result, the terminology used here differs from that used in the Standard, as shown in **Table 1-1** below.

Each Error message consists of three fields (Error Number, Error Message and Error Description), as shown in the table below (Events of this type are listed in “-221 Settings Conflict Errors” on page 46).

The SCPI query `:SYSTem:ERRor:NEXT?` returns a string containing these three fields. For more details, see the description of the query in the instrument's online help.

Additionally, most messages have an associated Verbose/Correction Explanation, which is provided **only** in this document and is not displayed in the instrument or returned via SCPI.

Table 1-1 Error Message Fields

Keysight Term	Error Number	Error Message	Error Description
SCPI Standard Term	Error/event Number	Error/event Description	Device-dependent info
Example	-221	Settings conflict	Electronic attenuator is disabled

For the example above, the Verbose/Correction Explanation is:

You are using the mechanical attenuator, and have not enabled the electronic attenuator. You cannot set the value of the electronic attenuator because it automatically sets/changes when enabled.

In this document, Event messages are listed in numerical order, according to their message number, except for Advisory Event messages, which do not have numbers and are listed in alphabetical order.

Condition messages are listed according to the number of their associated Start Event.

As specified in Volume 2, Section 21.8 of the **1999 SCPI Syntax & Style Standard**, messages with Error Numbers less than or equal to zero are predefined. The definitions listed in this document for those messages correspond to those in the Standard.

Event Queues & Displays

Events are logged into queues. Each source of control has its own queue. Thus there is a Front Panel queue, a SCPI GPIB queue, a SCPI LAN queue, and so on. Each remote queue is queried separately via its own interface.

The Front Panel queue may be viewed in two ways, via the Status or History lists, as described in [Table 1-2](#) below.

Error events generated by one interface may only be queried over that interface; for example, you cannot query GPIB errors from the LAN queue.

Note that Conditions are logged in the queues as pairs of Events: a Detected Event and a corresponding Cleared Event.

Table 1-2

Event Queue & Display Types

Front Panel Status (Current Conditions)	<p>A-Series: Messages can be viewed by pressing System, Show Errors, Status.</p> <p>B-Series: Displayed as a list in the Current Conditions tab of the Status Dialog.</p> <p>The Status/Current Conditions list shows existing conditions.</p> <p>When an event is caused by a command sent over a remote interface, the resulting messages are logged in the queue for that interface. For convenience, such Events are also logged in the Front Panel queue.</p>
Front Panel Event History	<p>A-Series: Messages can be viewed by pressing System, Show Errors, History.</p> <p>B-Series: Displayed as a list in the History tab of the Status Dialog.</p> <p>The History list shows all the events that have occurred since the instrument was turned on, up to a maximum of 100 messages.</p> <p>When an error situation is caused by a command sent over a remote interface, the resulting messages are logged in the queue for that interface. For convenience, they are also logged in the front panel queue.</p>
Remote interfaces	<p>When an error event is caused by a command sent over a remote interface, the resulting messages are output to the queue for that interface. To return an error, you must query the queue for that interface.</p> <p>An error event that is caused by a front panel action is not reported to any remote interface queue.</p> <p>However, a status condition is usually caused by an internal event that is not related to a particular interface, so the Detected/Cleared Events for status conditions are reported to all the queues.</p>

Table 1-3

Characteristics of the Event Queues

Characteristic	Front-Panel Status	Front-Panel History	Remote Interfaces (GPIB/LAN)
Capacity (maximum number of messages)	100	100	100
Overflow Handling	Circular (rotating). Drops oldest message as new message comes in.	Circular (rotating). Drops oldest message as new message comes in.	Linear, first-in/first-out. Replaces newest message with: -350, Queue overflow

Table 1-3 Characteristics of the Event Queues

Characteristic	Front-Panel Status	Front-Panel History	Remote Interfaces (GPIB/LAN)
Viewing Entries	A-Series: Press System , Show Errors, Status B-Series: Tap anywhere in the Status Bar	A-Series: Press System , Show Errors, History B-Series: Tap the Message Indicator balloon in the Status Bar	Send SCPI query to the desired interface: :SYSTem:ERRor?
Clearing the Queue	A-Series: Press System , Show Errors , Clear Error Queue B-Series: Select the History tab of the Status Dialog , then tap Clear Message Queue Clears the messages in all the queues.	A-Series: Press System , Show Errors , Clear Error Queue B-Series: Select the History tab of the Status Dialog , then tap Clear Message Queue Clears the messages in all the queues.	Send *CLS command to the desired interface. Clears messages in the queue for this particular interface only.

Table 1-4 Summary of Event Reporting Modes

Event Type	SCPI Error Queues	Front Panel History Queue	Status Panel Display
Error/Warning/Advisory Event	Logged	Logged	A-Series: displayed in Message Line B-Series: displayed via Message Box
Error/Warning Condition: Detected (Start) Event	Logged ^a	Logged ^a	A-Series: Displayed in Status Line B-Series: displayed via Message Box
Error/Warning Condition: Cleared (End) Event	Logged ^b		
Grayout Advisory (Benign)	Not logged	Logged	A-Series: Displayed in Status Line B-Series: displayed via Message Box
Grayout Advisory (Forced)	See note ^c	Logged	A-Series: Displayed in Status Line B-Series: displayed via Message Box

- a. Logged with the same severity (Error or Warning) as the Condition
- b. Logged with a “green” severity (Condition Resolved)
- c. Not logged, unless the cause of the Advisory was remotely generated, in which case a Warning message, type -221, is logged.


Message Display & Controls

A-Series

In A-Series instruments, messages are displayed as follows.

- Event messages appear in the **Message Line** at the bottom left of the instrument's display window, as shown in [Figure 1-1](#) below.
- Condition messages appear in the **Status Panel** at the bottom right of the instrument's display screen, as shown in [Figure 1-1](#) below.

Figure 1-1 Instrument Message Line & Status Panel for A-Series Instruments



B-Series

In B-Series instruments, messages are displayed as follows.

- Event Messages are displayed via popup **Event Message Boxes** that appear temporarily in the center of the screen.
- Condition Messages are displayed in the **Status Bar** at the bottom of the screen.

Event Message Boxes

A typical Event Message box is shown in [Figure 1-2](#) below. Event Message boxes appear in the center of the instrument screen when the event occurs, then fade away.

Figure 1-2

Event Message Box for B-Series Instruments



In the Message Box, the icon on the left indicates the appropriate Event category (see [Event Categories](#)): blue for Advisory, yellow for Warning, and red for Error.

For more details, see the topic **User Interface > Control Bar > Status Bar > Events** in the instrument's online help.


Status Bar

The Status Bar appears at the bottom of the display and contains three fields, as shown in [Figure 1-3](#) below.

Tapping anywhere in the Status Bar displays the [Status Dialog](#).

For full details of the fields in the Status Bar and their operation, see the topic [User Interface > Control Bar > Status Bar](#) in the instrument's online help.

Figure 1-3 Status Bar for B-Series Instruments



Status Dialog

The Status Dialog has three tabs:

1. History
2. Current Conditions
3. Settings

For full details of the tabs of the Status Dialog and their content, see the topic [User Interface > Control Bar > Status Bar > Status Dialog](#) in the instrument's online help.

2 Instrument Messages

This chapter includes the following sections:

- “Advisory Messages” on page 35
- “Event Messages” on page 41
- “Condition Messages” on page 82

Advisory Messages

An advisory is simply a message that lets you know something useful—for example “File saved successfully” or “Measuring fundamental.” Operation completion and running status indications are common types of Advisories.

Advisories have no number and are not logged in the error queue. They are not defined in the [1999 SCPI Syntax & Style Standard](#).

Advisories include gray-out “settings conflict” errors. These gray-outs are benign (that is, changing them has no impact on the current measurement).

Advisories are Events only. They are never Conditions.

Message; Description	Verbose/Correction Information
All Auto/Man functions have been set to Auto	Message generated by pressing the Auto Couple front-panel key.
Allowable Center Frequency exceeded for the current span	When rotating the knob or step up/down keys to change the Center frequency, the value of the Span is kept constant. Therefore, the center frequency is limited by the frequency range of the instrument.
Allowable Span exceeded for the current center frequency	When rotating the knob or step up/down keys to change the Span, the value of the Center frequency is kept constant. Therefore, the span is limited by the frequency range of the instrument.
Allowable Start Frequency exceeded for the current span	When rotating the knob or step up/down keys to change the Start frequency, the value of the Span is kept constant. Therefore, the start frequency is limited by the frequency range of the instrument.
Allowable Stop frequency exceeded for the current span	When rotating the knob or step up/down keys to change the Stop frequency, the value of the Span is kept constant. Therefore, the stop frequency is limited by the frequency range of the instrument.
Already in Single, press Restart to initiate a new sweep or sequence	The instrument is already in the single state. If you want to start a new sweep or sequence, press the Restart key instead.
Auto sweep time rules do not apply in FFT sweeps	FFT sweeps do not use the auto sweep time rules, so the rules setting cannot be changed from the front panel. The setting can be changed remotely and it will have no effect on the current operation unless the analyzer is switched out of FFT sweeps.
Band Adjust has no effect on a Fixed marker	If a Marker is a Fixed type marker, the marker's value does not change from when it first became fixed. So you cannot change the band of a fixed marker.
Band Adjust has no effect with Mkr Function Off	If Marker Function is off changing the band has no effect
Band-pass filter set to OFF	Turning on any high-pass or low-pass filter will turn off band pass filters.
Cal Cancelled; Calibration data cleared	User has canceled the cal either directly or indirectly by changing the setup parameters. The current cal data has been erased. Perform a new user cal to obtain calibrated results again.

Instrument Messages
Advisory Messages

Message; Description	Verbose/Correction Information
Cal Invalid: meas freq pt(s) > 3.6GHz are > 50MHz from existing Cal pts	When freq points being measured are above 3.6 GHz and a calibration has been successfully performed, and the number of points are changed, the new points are required to be within 50 MHz of the current cal points or the preselector optimize frequencies become inaccurate and the whole cal needs to be invalidated. Interpolation of the cal can only be performed if the new freq points are within 50 MHz of the cal points. To overcome this problem, change the number of freq points back to match cal points or perform another user cal.
Carrier power is too low for optimum dynamic range.	For better dynamic range, transmit band spur measurements require >10 dBm signal power at the RF input port.
Connecting to source...	External Signal Generator is being sent SCPI commands interrogating it to see if it is suitable for the MXA to control. Please wait until complete before pressing any buttons.
Demod Time is not available in Zero Span	The Demod Time function is not available in zero span because in zero span we are ALWAYS demodulating.
Detector <X> changed due to physical constraints	You have selected more detectors than the instrument hardware can implement. An existing detector selection has been changed to allow the current detector choice to be selected. <X> indicates the trace number for which the detector was changed.
Dynamic range is not optimum. Set AUTO RF input.	
Exp. Averaging not available when AUTO PhNoise is active.	
FFT Width is not settable unless Sweep Type is set to FFT	You must select the FFT sweep type before you can set the FFT Width
File <filename> saved	The file save operation executed successfully.
Filter BW function is only available for Gaussian filter type	Flattop and CISPR/MIL filters have defined shapes that cannot be altered. So only the Gaussian filter type allows filter bandwidth definition changes.
Fixed LO freq should be greater than RF Stop freq	The setup frequencies break the rules for a downconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The LO fixed freq should be greater than the RF freq's for an LSB or DSB (for DSB measurements the setup uses LSB values) downconverter setup. Use the graph icon on the DUT setup form to clarify the setup required.
Freq Scale Type=Log is not available in Zero Span	Logarithmic scaling cannot be used for time domain sweeps (0 Hz span).
Frequency Hopping enabled, waiting for valid burst	The demodulated burst type has not been found in the originally demodulated slot location within the frame.

Message; Description	Verbose/Correction Information
Frequency menu has changed to reflect frequency context switch	The frequency context parameter has been changed either by the user or the system. The frequency menu will now contain the frequencies for the new context. No action required.
Gate required for valid results	
High-pass and Low-pass filters set to OFF	Turning on any band pass filter will turn off high-pass and low-pass filters.
High-pass filter set to OFF	Turning on any band pass filter will turn off high-pass filters.
IF Fixed freq should be greater than LO Stop freq	The setup frequencies break the rules for an upconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The IF fixed freq should be greater than the LO Stop freq for a USB upconverter swept LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
IF Fixed freq should be greater than RF Stop freq	The setup frequencies break the rules for an upconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The IF fixed freq should be greater than the RF Stop freq for an upconverter swept LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
IF Start freq should be greater than LO Fixed freq	The setup frequencies break the rules for an upconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The IF start freq should be greater than the LO fixed freq for an USB upconverter fixed LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
IF Start freq should be greater than RF Start freq	The setup frequencies break the rules for an upconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The IF start freq should be greater than the RF Start freq for an upconverter fixed LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
Input is internal	The instrument's input is set to internal (the internal amplitude reference signal). So any signals connected to the front/rear panel inputs cannot be measured.
LO Fixed freq should be greater than IF Stop freq	The setup frequencies break the rules for an upconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The LO fixed freq should be greater than the IF Stop freq for an LSB upconverter fixed LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
LO Fixed freq should be greater than RF Stop freq	The setup frequencies break the rules for a downconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The LO fixed freq should be greater than the RF Stop freq's for an LSB or DSB (for DSB measurements the setup uses LSB values) downconverter fixed LO setup. Use the graph icon on the DUT setup form to clarify the setup required.

Message; Description	Verbose/Correction Information
LO Start freq should be greater than IF Fixed freq	The setup frequencies break the rules for an upconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The LO Start freq should be greater than the IF fixed freq for an LSB upconverter swept LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
LO Start freq should be greater than RF Start freq	The setup frequencies break the rules for a downconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The LO start freq should be greater than the RF Start freq's for an LSB downconverter swept LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
LO Stop freq should be greater than RF Stop freq	The setup frequencies break the rules for a downconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The LO Stop freq should be greater than the RF Stop freq's for a DSB (for DSB measurements the setup uses LSB values) downconverter swept LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
Low-pass filter set to OFF	Turning on any band pass filter will turn off low-pass filters.
No spurs have been found	You has started a measurement in examine meas type in single or continual sweep mode, or full meas type in single sweep mode, but no spurs were found.
Preparing Calculation...	
Preselector is centered	The preselector has been successfully centered
Preselector not used in this frequency range.	You cannot center or adjust the preselector because it is not used at all at the current marker frequency or between the current start and stop frequencies
Probe connected, cal data is being reapplied; <port>; <probe>	A probe has been connected, calibration data is being reapplied
Probe connected, no probe cal; using cable cal data; <port>; <probe>	A probe has been connected and no probe calibration data is available. The latest cable calibration data will be used
Probe disconnected, reverting to cable calibration data; <port>	A probe has been disconnected, calibration data reverting to the last cable calibration data
Reading SNS data...	The Keysight Smart Noise Source has been connected and the application is reading the device EEPROM data. Please wait until complete before continuing.
Recalled File <filename>	A file recall (open/load) was successfully completed.
Refer to online help for assistance with DSB measurements	The Double Side Band measurement requires careful setup to obtain valid results. Please refer to the manuals for help with this setup.
Requested timeslot number is not present.	The selected timeslot is not on. (Timeslot is referenced to the trigger point.)

Message; Description	Verbose/Correction Information
Res BW changed	In instruments with Option B5X, Span was set to > 255 MHz while Res BW was greater than Res BW 4.
RF Start freq should be greater than IF Fixed freq	The setup frequencies break the rules for a downconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The RF Start freq should be greater than the IF Fixed freq for a DSB (for DSB measurements the setup uses LSB values) downconverter swept LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
RF Start freq should be greater than IF start freq	The setup frequencies break the rules for a downconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The RF start freq should be greater than the IF Start freq's for an LSB downconverter fixed LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
RF Start freq should be greater than LO fixed freq	The setup frequencies break the rules for a downconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The RF start freq should be greater than the LO fixed freq's for an USB downconverter fixed LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
RF Start freq should be greater than LO Start freq	The setup frequencies break the rules for a downconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The RF start freq should be greater than the LO Start freq's for an USB downconverter swept LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
RF Stop freq should be greater than IF Stop freq	The setup frequencies break the rules for a downconverter measurement. The measurement will still run, but check setup frequencies are correct before continuing. The RF Stop freq should be greater than the IF Stop freq's for an USB or DSB (for DSB measurements the setup uses LSB values) downconverter fixed LO setup. Use the graph icon on the DUT setup form to clarify the setup required.
Scale/Div only applies in Log Y Scale	Setting the Scale/Division only makes sense when you are using a logarithmic Y scale.
Signal Track is turned off when Zero Span is selected	Signal Track is not available when you have selected Zero Span. So if Zero Span is entered while in Signal Track is On, Signal Track is turned off.
Signals deleted	The signals in the signal list were successfully deleted.
Sweep Points/Span is < minimum. Results may be inaccurate.	The sweep point to span ratio is below the minimum required to ensure the bucket ratio is large enough to test DVB-T masks
Sweep Setup is not available in Zero Span	Zero span is a display at a single frequency, so there is no "sweeping" to set up.
Sync is RF Ampl (not Training Sequence). Bits are not accurate.	
Trace file saved.	The trace saving operation was successful.

Instrument Messages
Advisory Messages

Message; Description	Verbose/Correction Information
Use Gate View Sweep Time in the Gate menu.	When in Gate View you use Gate View Sweep Time, rather than Sweep Time, to control the Gate View window
User Cal valid. Apply Cal from Meas Setup menu	The measurement setup has changed such that the current cal data can be applied to the results. To apply the cal, press Meas Setup/Cal Setup/Apply Calibration. A new cal can be performed if required.

Event Messages

Event messages and message numbers are defined by the [1999 SCPI Syntax & Style Standard](#). All message numbers are less than or equal to zero.

The SCPI Standard refers to all these messages as "Error/event Messages". Most X-Series Event Messages fall into the Error Category (see ["Event Categories" on page 26](#)), but a small number are Warnings, as noted for the relevant entries below.

Device-dependent sub-messages are often appended, to provide additional information. For example, error -221 is defined as `Settings Conflict`, but you will often see a longer description appended to error -221, such as `Settings Conflict; Function not available in Zero Span`. This provides more information about why there is a Settings Conflict error.

The tables in this section are divided by Error Number range, as follows:

- ["-800, Operation Complete Event" on page 42](#)
- ["-700, Request Control Event" on page 42](#)
- ["-600, User Request Event " on page 42](#)
- ["-500, Power on Event " on page 42](#)
- ["-400 to -499, Query Errors" on page 42](#)
- ["-300 to -399, Device-Specific Errors" on page 44](#)
- ["-221 Settings Conflict Errors" on page 46](#)
- ["-200 to -299, Execution Errors" on page 63](#)
- ["-100 to -199, Command Errors" on page 79](#)
- ["0 No Error" on page 81](#)

-800, Operation Complete Event

Error Number	Message; Description	Verbose/Correction Information
-800	Operation complete	The instrument has completed all selected pending operations in accordance with the IEEE 488.2, 12.5.2 synchronization protocol.
-800	Operation complete; Loaded <ARB filename> successfully, but no license <required licenses> installed	This is a Warning , and is GUI only, that is, this warning cannot queried by SCPI. It indicates that the ARB is successfully loaded into ARB memory, but requires licenses that are not present on the instrument. Install the required license(s) according to <required license> string to license it or multi-pack license it.

-700, Request Control Event

Error Number	Message; Description	Verbose/Correction Information
-700	Request control	The instrument requested to become the active IEEE 488.1 controller-in-charge.

-600, User Request Event

Error Number	Message; Description	Verbose/Correction Information
-600	User request	The instrument has detected the activation of a user request local control.

-500, Power on Event

Error Number	Message; Description	Verbose/Correction Information
-500	Power on	The instrument has detected an off to on transition in its power supply.

-400 to -499, Query Errors

Error Number	Message; Description	Verbose/Correction Information
-400	Query Error	There was a problem with a query command. The exact problem cannot be specifically identified.
-410	Query INTERRUPTED	Some condition caused an INTERRUPTED query to occur. For example, a query was followed by DAB or GET before a response was completely sent.
-420	Query UNTERMINATED	Some condition caused an UNTERMINATED query to occur. For example, the device was addressed to talk and an incomplete program message was received.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-430	Query DEADLOCKED	Some condition caused a DEADLOCKED query to occur. For example, both the input buffer and the output buffer are full and the analyzer cannot continue. The analyzer automatically discards output to correct the deadlock.
-440	Query UNTERMINATED after indefinite response	A query was received in the same program message after a query requesting an indefinite response was executed.

-300 to -399, Device-Specific Errors

Error Number	Message; Description	Verbose/Correction Information
-300	Device-specific error	An instrument error occurred and the exact problem cannot be specifically identified. Report this error to the nearest Keysight Technologies sales or service office.
-310	System error;	An internal system-type error has occurred. The exact problem cannot be specifically identified. Report this error to the nearest Keysight Technologies sales or service office.
-310	System error; <feature> expired, please reboot within <time>	The trial license for the specified feature, for example "N9030T-RT1, has expired. You must finish any measurements in process and reboot the instrument within the time specified.
-310	System error; <feature> expired, rebooting in <time>	The trial license for the specified feature, for example "N9030T-RT1, has expired. The instrument will automatically reboot at the time specified; you should save your measurement results immediately.
-310	System error; A license will soon expire; <feature code> will expire in <time>	The indicated feature/software will expire in the specified time. Contact Keysight Technologies to purchase continued use of this functionality.
-310	System Error; enable GPIB controller mode	Press System, I/O Config, GPIB and set GPIB Controller to Enabled so that the instrument can control the source over GPIB
-310	System error; feature <feature code> not licensed	The specified feature, for example "N9073A-TR2" is not licensed. The license may have expired. You cannot use it until you get a license.
-310	System error; Feature expired; <feature code>	The specified feature has expired. The license is no longer valid.
-310	System error; License installation failed; <feature code>	The license installation of the specified feature, for example "N9073A-TR2", has failed. You should refer to the event log in the control panel for more details.
-310	System error; License removal failed; <feature code>	The license removal of the specified feature, for example "N9073A-TR2" has failed. You should refer to the event log in the control panel for more details.
-310	System error; No license; <feature code> will terminate in <time>	The specified feature will stop working in the specified time due to the license expiration You will be prompted to save results and exit.
-310	System Error; No supported source found	Signal source at given IP address is not responding / IP does not belong to a source. Check IP address and network connection.
-310	System Error; source connection lost, check interface connection	Signal source at given IP address is not responding / IP does not belong to a source. Check IP address and network connection.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-311	Memory error	There is a physical problem with the instrument memory, such as a parity error.
-312	PUD memory lost	Protected user data saved by the *PUD command has been lost.
-313	Calibration memory lost	The nonvolatile calibration data used by the *CAL? command has been lost.
-314	Save/recall memory lost	The nonvolatile data saved by the *SAV? command has been lost.
-315	Configuration memory lost	The nonvolatile configuration data saved by the instrument has been lost.
-320	Storage fault;	A problem was found while using data storage. The error is not an indication of physical damage or failure of any mass storage element.
-321	Out of memory	An internal operation needed more memory than was available. Report this error to the nearest Keysight Technologies sales or service office.
-321	Out of memory; Results truncated	Reduce the acquisition count, analysis step count, or measurement count.
-321	Out of memory; Sequence too long	The Sequence is too large to be captured. Reduce the Number of Acquisitions or the Acquisition Duration of each Acquisition.
-321	Out of memory; Total analysis step reaches its limitation	Reduce the analysis steps count.
-340	Calibration failed; <failure msg><port>	The calibration for one of the I-Q ports did not succeed. The information in the "failure msg" field can be used to troubleshoot this problem. Contact Keysight technical support.
-350	Queue overflow	An error occurred that did not get put in the error queue because the queue was full.
-360	Communication error	There was a problem with instrument remote communications. The exact problem cannot be specifically identified.
-360	Communication error; SNS data read failure. Disconnect then reconnect SNS	The Keysight Smart Noise Source connected to the MXA has failed to be read by the application. Please disconnect and reconnect the SNS. If this continues to fail, then the SNS may have had its EEPROM corrupted or another hardware fault exists. Check SNS on another instrument, NFA and ESA are also SNS compatible instruments. Check the device is not an Keysight power sensor which uses the same cable interface.
-360	Communication error; SNS is not connected	The Keysight Smart Noise Source connected to the MXA has failed to be read by the application. Please disconnect and reconnect the SNS. If this continues to fail, then the SNS may have had its EEPROM corrupted or another hardware fault exists. Check SNS on another instrument, NFA and ESA are also SNS compatible instruments. Check the device is not an Keysight power sensor which uses the same cable interface.

Error Number	Message; Description	Verbose/Correction Information
-361	Parity error in program message	A parity bit was not correct when the data was received. For example, on a parallel port.
-362	Framing error in program message	A stop bit was not detected when data was received. For example, on a remote bus port.
-363	Input buffer overrun	A software or hardware input buffer on a port overflowed with data because of improper or nonexistent pacing.
-365	Time out error	There was a time-out problem in the instrument. The exact problem cannot be specifically identified.
-365	Time out error; Operation on source is held. If analyzer is waiting for trigger, change to free run to proceed	<p>This is a Warning message.</p> <p>This warning can only occur when issuing SCPI to operate the source while the analyzer is waiting for a trigger. When the analyzer is waiting for a trigger, source operation is set to pending. (Trigger Source operation is an exception)</p> <p>To avoid this, do not operate the source when the analyzer is waiting for a trigger. If source and analyzer both are utilized, configure the source parameters ready and run before analyzer waits for trigger.</p> <p>If both the analyzer and source are waiting for a trigger, the only operations allowed on the source are trigger source operations, like external, manual, or bus trigger.</p>

-221 Settings Conflict Errors

This is one of the messages in the standard SCPI range from “-200 to -299, Execution Errors” on page 63.

Error Number	Message; Description	Verbose/Correction Information
-221	De-emphasis only available in FM	The de-emphasis function is only available if FM demod is selected.
-221	Function not available in Zero Span	The function you are trying to access is not available in zero span.
-221	Setting conflict; <trigger source> trigger is not available while input is <input port>	The trigger source (Video, RF Burst, I/Q Mag, etc.) is not available with the current input port (RF, IQ, etc.)
-221	Setting conflict; Acquisition # Analysis Step # not exist	<p>The configured Analysis Step does not exist.</p> <p>Add the specified analysis step into the sequence.</p>
-221	Setting conflict; Acquisition # not exist.	<p>The configured acquisition does not exist.</p> <p>Add the specified acquisition into this sequence.</p>

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-221	Setting conflict; Acquisition duration time too short, Acq=#	Acquisition duration cannot be less than < (analysis offset + analysis interval). Increase the acquisition duration time or decrease the analysis offset and analysis interval.
-221	Setting conflict; Analysis Interval should be less than ** ms, Acq=# Step=#	The analysis interval is too large for basic transmit power measurement. Decrease the analysis interval.
-221	Setting conflict; Analysis Offset should be greater than # us, Acq=# Step=#	The Analysis Offset should be greater than # μ s due to physics requirement. Increase the time of Analysis Offset.
-221	Setting conflict; Auto Set RF Level failed, Too much dynamic range is requested	The sequence requests too much dynamic range, auto range cannot be preformed correctly. Change the Peak Power or DUT Expected Power.
-221	Setting conflict; Averaged acquisition duration time exceeds maximum value, Acq=#	Total acquisition duration time after averaging (average count * acquisition duration) exceeds maximum value. Reduce the average count or decrease the acquisition duration time.
-221	Setting conflict; Basic Discrete PAVT measurement cannot be averaged, Acq=# Step=#	The average count of acquisition which contains basic Discrete PAVT measurement cannot be greater than 1. Set the average count of current acquisition to 1. Or remove the Basic Discrete PAVT measurement from this analysis step.
-221	Setting conflict; Basic IQ data measurement cannot be averaged, Acq=# Step=#	The average count of acquisition which contains basic IQ data measurement cannot be greater than 1. Set the average count of current acquisition to 1. Or remove the Basic IQ data measurement from this analysis step.
-221	Setting conflict; Cannot delete current step, minimum number of steps reached	An attempt was made to delete the current step which is already the only step in the list sequence.
-221	Setting conflict; Cannot insert more steps, maximum number of steps reached	An attempt was made to insert more steps into list sequence which already contains the maximum of 1000 steps.
-221	Setting conflict; Differential setting determined by probe type	A probe is connected that has a built in Differential setting. The setting cannot be changed manually.

Error Number	Message; Description	Verbose/Correction Information
-221	Setting conflict; DUT Expected Power cannot be greater than Peak Power, Acq=# Step=#	Changing Peak Power will cause DUT Expected Power to be clipped.
-221	Setting conflict; Input Z unavailable when probe sensed	A probe is connected and the Input Z is set based on the probe type. It cannot be changed manually.
-221	Setting conflict; Instrument Gain LOW is not supported when frequency > 3.6 GHz. Auto change it to ZERO, Acq=#	When the acquisition frequency is change to be greater than 3.6GHz, the Instrument Gain will be set to ZERO automatically if the current value is LOW. This is a Warning message, no action is required.
-221	Setting conflict; Measurement Bitmap *** not available in Radio Standard ***, Acq=#	The configured measurement is not supported by the current radio standard. Remove this measurement from the current acquisition or change the radio standard of the current acquisition.
-221	Setting conflict; PAVT step end time exceeds the analysis interval	The end time of PAVT measurement exceeds the analysis interval. Decrease the end time of PAVT or increase the Analysis interval.
-221	Setting conflict; PAVT step start time is less than zero	The start time of PAVT measurement cannot be less than ZERO.
-221	Setting conflict; Phase Discontinuity measurement cannot be averaged, Acq=# Step=#	The average count of acquisition which contains Phase Discontinuity measurement cannot be greater than 1. Set the average count of current acquisition to 1. Or remove the Phase Discontinuity measurement from this analysis step.
-221	Setting conflict; Radio Band *** not available in Radio Standard ***, Acq=#	The radio band is not supported by the selected Radio Standard. Change the radio band.
-221	Setting conflict; Radio Device BTS not supported, Acq=#	Sequence analyzer does not support BTS. Change the device type of the acquisition radio standard related mode to MS. For example: if acquisition 3 is configured as WCDMA, so you should change the device type of WCDMA mode to MS.
-221	Setting conflict; Radio Standard *** not available, Acq=#	The radio standard related application is not preloaded. Manually switch to the radio standard related mode and switch back to Sequence Analyzer mode. Or select this mode as preloaded in configure-application panel and then restart.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-221	Setting conflict; RF Envelope trace is not available without Basic IQ data measurement, Acq=# Step=#	RF envelope view is available only when the selected analysis step contains basic IQ data measurement. Configure Basic IQ data measurement into current analysis step or switch the view to Result Metrics.
-221	Setting conflict; Sequence too long, Acq = #	The duration of the whole sequence is too long. With current configurations, The Sequence can only handle #-1 Acquisitions.
-221	Setting conflict; Transition Time should be greater than # us, Acq=#	The transition time of acquisition # should be greater than physics required minimum time. Increase the transition time.
-221	Setting conflict; Trigger Delay should be greater than # us, Acq=#	The trigger delay of acquisition # should be greater than physics required minimum time. Increase the time of trigger delay.
-221	Setting conflict; Trigger Level is too low, Acq=#	The Trigger Level on the specified Acquisition is too low, so that the test-set cannot be triggered correctly. Increase the trigger level.
-221	Setting conflict; Transition time may be short on step <step number>.	An attempt was made to set the source step transition time to a value shorter than the hardware settling time This is provide as a Warning . Instrument operation may not be impacted because the hardware could settle more quickly than is normal. You can eliminate this warning by setting a longer transition time.
-221	Settings Conflict: Timebase DAC not available with Pulse selected	The manual adjustment of the Timebase DAC cannot be performed when the currently selected timebase is Pulse.
-221	Settings conflict;	A legal command was received but it could not be executed due to the current device state.
-221	Settings conflict; *.CSV file format is not available in this measurement.	You cannot load or save base instrument traces, as this is not supported by the Log Plot measurement.
-221	Settings conflict; <Q Param> cannot be changed when Q same as I	When the "Q Same as I" parameter is set to Yes, the I parameter value is copied to <Q Param> and the <Q Param> value cannot be changed. Set Q Same as I to No to enable explicit control of the <Q Param> value.
-221	Settings conflict; A Valid User Cal is required. Optimize aborted	Optimize Preselector can only be performed if a valid user cal exists and is applied to current results. Perform a user cal first or apply existing cal.

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; At least one Phase must be turned on	
-221	Settings conflict; At least one Protective Earth must be turned on	At least one Protective Earth must be turned on
-221	Settings conflict; Auto Tune not available in Tracking Source mode	The Auto Tune feature cannot be used when you are using a Tracking Source.
-221	Settings conflict; BTS gain is not available in this Mode	Base Transceiver Station gain correction is not available in some Modes, or in some measurements (for example, the SA measurement).
-221	Settings conflict; Cal only available when Source Mode is Tracking	You must be in Tracking Source mode to use the Cal functions under Normalize. Press Source, Source Mode and set it to Tracking.
-221	Settings conflict; Calibration cannot be performed without valid ENR data	The cal ENR table has no values in it, and hence the cal cannot be performed. Correct by either populating the cal ENR table, set ENR mode to Spot, or set the 'Use Meas Table Data for Cal' to 'On'.
-221	Settings conflict; Cancellation is not available while measuring DANL floor.	Phase Noise cancellation does not make sense when measuring the DANL Floor, so for this reason it has been disabled
-221	Settings conflict; Cancellation Ref trace has no data.	When performing phase noise cancellation, you need to supply a reference trace that will be used to cancel out the background noise of the analyzer. The reference trace must be in Reference (View) mode, and selected by the Ref Trace parameter under the Cancellation menu
-221	Settings Conflict; Cancellation trace has different X-Scale	Reference trace for the cancellation has a different range of X-axis against the target trace
-221	Settings conflict; Cannot optimize while user cal in progress	Optimize Preselector cannot be performed while a user cal is in progress. The user cal performs an optimize preselector prior to taking the noise source on/off level results for the cal data.
-221	Settings conflict; Can't Auto-Couple Res BW in Zero Span	The resolution bandwidth cannot be set to auto while you are in zero span (time domain).
-221	Settings conflict; Carrier freq not allowed with BMT. (Bottom/Middle/Top only)	The transmit band spur measurement only allows bottom (B), middle (M), and top (T) channel frequencies for each supported frequency band. The carrier frequency must be set to the bottom, middle or top frequency of the current frequency band.

Error Number	Message; Description	Verbose/Correction Information
-221	Settings Conflict; Code channel duplication	This error is reported when the given code channel overlaps other code channel
-221	Settings conflict; Cont Mode is not available	Current measurement does not support Continuous Sweep, only Single Sweep is available
-221	Settings conflict; Continuous Peak is not available with Fixed marker	The continuous peak feature cannot be used with a marker that is fixed. By definition that marker value cannot change.
-221	Settings conflict; Continuous Peak is not available with Signal Track on	The continuous peak feature cannot be used while you are also using the signal tracking function.
-221	Settings Conflict; Correction file not specified	Correction file has not been specified. There is no file to be removed.
-221	Settings Conflict; Correction not available with Corr Group on	Correction is not available with Correction Group turned on.
-221	Settings conflict; dB*/MHz is not applicable to the following Y-Axis units, dBm, W, V, A	You cannot turn on dB*/MHz for Y-Axis units: dBm, W, V, A. It is not applicable to these units.
-221	Settings conflict; Destination trace for Trace Math cannot be a trace operand	The resulting trace data (from doing a trace math function) cannot be put into the any of the traces that are being used by the math operation.
-221	Settings conflict; Downconv only available when DUT is Amplifier	SCPI only message. The System Downconverter can only be set to 'On' when the DUT type is amplifier. Change DUT type to Amplifier if the System Downconverter is required.
-221	Settings conflict; EDGE EVM only supports EDGE TCH burst type.	
-221	Settings conflict; Electronic attenuator is disabled	You are using the mechanical attenuator, and have not enabled the electronic attenuator. You cannot set the value of the electronic attenuator because it automatically sets/changes when enabled.
-221	Settings conflict; Electronic attenuator is not available above 3.6 GHz	The maximum frequency of the electronic attenuator is 3.6 GHz. This is because of switching capacitance.

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Electronic attenuator unavailable in current state	
-221	Settings conflict; Electronic attenuator unavailable with Preamp on	The internal preamp is on. Electronic attenuator cannot be used while you are using the internal preamp.
-221	Settings conflict; EMI Avg/RMS Avg and Average detector can't be used together	User is not allowed to turn on any EMI Avg/RMS Avg and Average detector together. They are always mutually exclusive.
-221	Settings conflict; EMI Detectors are not available in FFT sweep	QPD, EMI Average, EMI Peak, and MIL Peak are not allowed when in the manually selected FFT sweep mode.
-221	Settings conflict; Enabled modulation source conflicts with previous modulation source. Previous modulation disabled	Turning one modulation format (like AM, PM, FM or ARB) on when another modulation format is already on results in the previous modulation format being turned off and the generation of an error.
-221	Settings conflict; External Mixer not available	A command has been sent to reference the External Mixer in a model that does not contain it
-221	Settings Conflict; FAST method can only be used while Radio Std is W-CDMA	
-221	Settings conflict; Feature not available for Option <abc>	This functionality is not part of the instrument configured with the indicated option
-221	Settings conflict; Feature not available in this View	Some functionality is available in one View, but not in another. (See the Views under the View/Display key.) This error occurs if you send a SCPI command or push a grayed-out key that is not available in the currently selected View.
-221	Settings conflict; Feature not supported for selected source	You have asked for a feature that the selected source does not support
-221	Settings conflict; Feature not supported for this Input.	Some functionality is not available when certain Inputs are selected. For example, Trigger Holdoff is not available for the BBIQ input

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Feature not supported for this measurement.	Some functionality is available in one measurement, but not in another. (See the measurements under the Meas key.) This error occurs if you send a SCPI command or push a gray-out key that is not available in the current selected measurement.
-221	Settings conflict; Feature not supported for this model number	This functionality is not a part of the instrument you are using but may be found in other models in the X-Series.
-221	Settings conflict; FFT IF Gain High not available when Swept IF Gain = Manual Low	When Swept IF Gain is manually set to Low, you cannot set the FFT IF Gain to High because that would make the Reference Level couplings wrong in FFT mode.
-221	Settings conflict; FFT method is unavailable for level gating	If you are using level gating, you cannot select the FFT Gate Method.
-221	Settings conflict; FFT sweep type is not available while in Gated LO	The gated LO function turns the LO on and off as it sweeps. So the FFT sweep type is not available if you have selected gated LO.
-221	Settings conflict; FFT sweep type is not available while in Gated Video	The FFT sweep type is not available if you have selected the gated video function.
-221	Settings conflict; FFT Sweeps unavailable in Tracking Source mode	Since FFT's do not sweep, you cannot use a Tracking Source while doing FFT's
-221	Settings conflict; Fixed marker adjust not available while Marker Function is on	If a Marker Function is on for a Fixed marker, the marker's reported value is derived from the function. Therefore, you cannot directly set the X or Y value of a Fixed marker that has a marker function turned on.
-221	Settings conflict; Fixed Marker Y value is not adjustable with Normalize On	If Normalize is on the Amplitude scale is in dB units, so adjusting the Y value of a Fixed marker is not possible.
-221	Settings conflict; Freq > 3.6 GHz unavailable while electronic attenuator enabled	The electronic attenuator does not function above 3.6 GHz. So if you have that attenuator enabled, you cannot change the center frequency so that frequencies above 3.6 GHz are displayed/measured.
-221	Settings Conflict; frequency is outside available range	The desired frequency is not a valid setting.
-221	Settings Conflict; Function not available in Correction Trace Display.	The correction trace for the selected range is turned on. There is no range to setup, If you want to edit the range, turn off correction trace display.

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Function not available in External Mixing	The frequency offset feature cannot be used when you have selected a log scale for the frequency axis.
-221	Settings conflict; Function not available in Tracking Source mode	The feature cannot be used when you are using a Tracking Source.
-221	Settings conflict; Function not available while running multirange scan	Settings change is not allowed while multirange scan is running. You must stop the current measurement if you wish to change the settings.
-221	Settings conflict; Function not available with current LISN Type	Not all functionality is available for all LISN types
-221	Settings conflict; Function not available with time domain scan type.	Scan Time and Points not supported in TDS
-221	Settings conflict; Function only available in Tracking Source mode	The feature cannot be used unless you are using a Tracking Source.
-221	Settings conflict; Function unavailable with MW Presel off	You cannot center or adjust the preselector because the Microwave Preselector is currently off
-221	Settings conflict; Function unavailable with this EMC Standard	Filter BW is auto-coupled when EMC Standard is set to CISPR or MIL. You must set the EMC standard to None if you are to change the Filter BW.
-221	Settings conflict; Gate control is Edge for Gated FFT	You cannot use level triggering to control the gate if you are using the FFT gating method.
-221	Settings conflict; Gate control must be Edge for this Gate Source	You cannot use level triggering to control the gate when you are using the currently selected gate source.
-221	Settings conflict; Gate is not available when Marker Count on	The gate function cannot be used while you have marker count turned on.
-221	Settings conflict; Gate Length is not settable in FFT sweeps	The sweep time for FFT sweeps is set by the calculations. So sweep time settings cannot be adjusted.
-221	Settings conflict; Gate Length is not settable in FFT sweeps	The sweep time for FFT sweeps is set by the calculations. So sweep time settings cannot be adjusted.

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Gate Method is not compatible with current Sweep Type setting	If the Gate is On and you have the FFT Sweep Type manually selected, then the Gate Method cannot be selected.
-221	Settings conflict; Gate not available with external Tracking Source	The Gate functions are unavailable when Source Mode is Tracking with an external source. This is because the Gate circuitry is used to sync the external source.
-221	Settings conflict; Gate not available with Tracking Generator	If the Source Type is Tracking Generator, the Gate circuitry is used for TG sync and is not available for gating
-221	Settings conflict; Gated FFT is not available while Sweep Type is set to Swept	The gated FFT function is not available if you have selected the swept type of sweep. You must be in the FFT sweep type.
-221	Settings conflict; Gated LO is not available while Sweep Type is set to FFT	The FFT sweep type moves the LO frequency in steps. So the gated LO function is not available if you have selected FFT sweep.
-221	Settings conflict; Gated Video is not available while Sweep Type is set to FFT	The gated video function is not available if you have selected the FFT sweep type.
-221	Settings conflict; Incorrect RBW for demod. Change RBW	
-221	Settings conflict; Ind I/Q is not available for this measurement	The Independent I and Q setting is not available for the current measurement. Only some measurements (initially, only VXA) support this setting.
-221	Settings conflict; Invalid trace number	The subopcode used to specify the trace number is invalid for this measurement or query
-221	Settings conflict; Knob is not available to modify this function	You should select a specific value for this function. So scrolling through values with the knob is not allowed.
-221	Settings conflict; Limit cannot be auto-coupled while freq is out of CISPR14 range	Settings conflict; Limit cannot be auto-coupled while freq is out of CISPR14 range
-221	Settings conflict; LO Phase Noise Adj not available	For instruments without the Dual-Loop LO, this feature is not available
-221	Settings conflict; Marker 1 Trace Update=off turns off Signal Track	Signal Track not available unless the trace containing Marker 1 is updating

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Marker cannot be relative to itself	A marker must be set relative to another marker, not to itself.
-221	Settings conflict; Marker Count is not available when Gate on	The marker count function cannot be used while you have gating turned on.
-221	Settings conflict; Marker Function is not available for a Fixed marker	If a Marker is a Fixed type marker, the marker's value does not change from when it first became fixed. You cannot turn on or change a Marker Function because there is no ongoing measurement data to use for the marker function calculation.
-221	Settings conflict; Marker type must be delta	Mkr?->Span and Mkr?->CF require that the selected marker be a delta marker.
-221	Settings conflict; Marker-> function is not available in zero span	Most of the "Marker To" functions are not available if you are in zero span (span = 0 Hz, or time domain). So you cannot send the commands for these functions.
-221	Settings conflict; Mask unavailable for current Span. Increase to display mask.	The current span setting is either narrower than the mask width or so wide that there are too few display points to allow the mask to be drawn. Increase or decrease the span to display the mask.
-221	Settings conflict; Meas Type was changed to Examine for Exp Avg Mode.	Average Mode has been changed to Exponential. Full Meas Type is not available for Exponential Average Mode therefore Meas Type has been changed to Examine.
-221	Settings conflict; Meas Type was changed to Full for Repeat Avg Mode	Average Mode has been changed to Repeat. Examine Meas Type is not available for Repeat Average Mode therefore Meas Type has been changed to Full.
-221	Settings Conflict; MinPts/RBW limit not met	
-221	Settings conflict; Mkr -> CF is not available when the x-axis is time domain	The marker to center frequency functionality does not work when the x-axis is in the time domain.
-221	Settings conflict; Mod Scheme AutoDet unavailable when Burst Sync=RF Amptd	The modulation scheme auto detection is unavailable when the burst sync is set to RF Amptd (GSM/EDGE)
-221	Settings conflict; MPA GPS port power setting <n>dBm is lower than -130dBm minimum	Indicating the power output setting (UI power + Amp Corr Value) on MPA GPS port is lower than supportable minimum -130dBm. Set power output setting to be larger than -130dBm to eliminate this warning.

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; MPA TX port<n> amplitude correction delta exceeds <n>dB between port<n1> and port<n2>	Indicating the amplitude correction delta value between MPA TX port<n1> and port<n2> for MXG mode (port difference) exceeds max loss delta value. Set related amplitude correction delta value to be lower than the max loss delta value given in error message.
-221	Settings conflict; MPA TX port<n> amplitude correction value <n>dB is out of range. The valid range is <n> ~ <n>dB"	Indicating the amplitude correction value of MPA TX port<n> for MXG mode is out of range. Set related amplitude correction value within the valid range given in error message.
-221	Settings conflict; MPA TX port<n> power setting <n>dBm is lower than -130dBm minimum	Indicating the power output setting (UI power + Amp Corr Value) on MPA TX port<n> is lower than supportable minimum -130dBm. Set power output setting to be larger than -130dBm to eliminate this warning.
-221	Settings conflict; MS gain is not available in this Mode	Mobile Station gain correction is not available in some Modes, or in some measurements (for example, the SA measurement).
-221	Settings conflict; Must apply Amplitude Correction to make this unit available	These special units only apply when you are doing antenna measurements so you have to have a correction which includes Antenna Units enabled
-221	Settings conflict; No meas frequencies are above 3.6 GHz	Optimize Preselector can only be performed on frequencies in high band, that is, frequencies above 3.6 GHz. The current setup does not have input freqs (IF) in this range so an Optimize Preselector cannot be performed.
-221	Settings conflict; no source selected	You must select a source using Select Source before you can do this
-221	Settings conflict; No Stepped Scan Type	Discrete Scan Type does not appear in this model
-221	Settings conflict; Normalize is not available when Scale Type = Lin	Normalize does not support Linear amplitude scale, since the results are always presented as a dB ratio.
-221	Settings conflict; Normalize is not available while Demod View is on	The normalization (correction) function cannot be used if you are using the Demod View.
-221	Settings conflict; Normalize is not available while Trace Math is on	The Normalize function works by doing trace manipulation, so if trace math is on you cannot turn on normalization.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Only active Antenna Unit available; no other Y axis units	When a correction with antenna units is turned on, the only Y-Axis units you can have are those that match the Antenna Unit. Turn off the Correction or the Antenna Unit under Input/Output, Corrections
-221	Settings conflict; Option not available	You have attempted to perform an action for which a required option is not installed
-221	Settings conflict; Param only available when DUT is a freq converter	SCPI only message. The sideband and freq context parameters are only available when a freq conversion setup is in use. Change setup to contain a freq conversion to use these parameters.
-221	Settings conflict; Param only available when External LO Mode is Swept	SCPI only message. This parameter is only available when the LO mode is set to Swept. Change the LO Mode to Swept.
-221	Settings conflict; Param only available when External LO Mode is Fixed	SCPI only message. This parameter is only available when the LO mode is set to Fixed. Change the Freq Mode to Fixed.
-221	Settings conflict; Param only available when Frequency Mode is Fixed	SCPI only message. This parameter is only available when the Freq mode is set to Fixed. Change the Freq Mode to Fixed.
-221	Settings conflict; Param only available when Frequency Mode is Swept	SCPI only message. This parameter is only available when the Freq mode is set to Swept. Change the Freq Mode to Swept
-221	Settings conflict; Param only available when valid cal data exists	SCPI only message. The 'Apply Calibration' parameter is only available when the stored cal data matches the current setup. Perform a fresh 'Calibrate Now' or change setup such that current cal data is valid.
-221	Settings conflict; Power search is not available when ALC is On	Cannot do power search when ALC is On.
-221	Settings conflict; Power search is not available when RF is Off	Cannot do power search when RF is Off.
-221	Settings conflict; Power search is not available when trigger type is not free-run	Cannot do power search when trigger type is not free-run.
-221	Settings conflict; Preamp gain is not available in this Mode	Preamp gain correction is not available in some Modes or Measurements
-221	Settings conflict; Preamp unavailable with electronic attenuator on	The electronic attenuator is on. Internal preamp cannot be used while you are using the electronic attenuator.

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Reference marker must be in same window	A delta marker and its reference must be in the same window. This error occurs when you try to turn on a delta marker who's reference is in a different window.
-221	Settings conflict; Relative Trigger needs hardware support for this meas	To do Relative Triggering in this measurement requires optional hardware that is not present in this analyzer.
-221	Settings conflict; Scale Type = Lin is not available when Normalize is on	Only the Log amplitude scale is available in Normalize, since the results are always presented as a dB ratio.
-221	Settings conflict; Sequence may have gaps when playing step <n>, if next step trigger comes later than current step expires	This is a Warning . The you set step duration type of step n to Time or Play Count while the Step Trigger of step n+1 is not set to "Free Run". So if next step trigger comes later than the expiration of the current step play time, the ARB will stop playing and cause a gap between steps.
-221	Settings conflict; Settings conflict; Pre-trigger is insufficient for demod. Decrease Trig Delay.	
-221	Settings conflict; Signal Track is not available with Continuous Peak	The signal tracking feature cannot be used while you are also using the continuous peak function.
-221	Settings conflict; Signal Track is only available in Swept SA measurement	The signal track functionality can be used when making a swept SA measurement. It is not available in the SA measurement when you are using FFT sweeps.
-221	Settings conflict; Signal Track is turned off when Zero Span is selected	Signal Track is not available when you have selected Zero Span. So if Zero Span is entered while in Signal Track is On, Signal Track is turned off.
-221	Settings conflict; Source List Step<n> MPA GPS port power setting <n>dBm is lower than -130dBm minimum	Indicating the power output setting (UI power + Amp Corr Value) on MPA GPS port on Source List Step<n> is lower than supportable minimum -130dBm. Set power output setting to be larger than -130dBm to eliminate this warning.
-221	Settings conflict; Source List Step<n> MPA TX port<n> amplitude correction value <n>dB is out of range. The valid range is <n> ~ <n>dB"	Indicating the amplitude correction value of MPA TX port<n> on Source List Step<n> is out of range. Set related amplitude correction value within the valid range given in error message.

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Source List Step<n> MPA TX port<n> amplitude correction delta exceeds <n>dB between port<n1> and port<n2>	Indicating the amplitude correction delta value between MPA TX port<n1> and port<n2> on Source List Step<n> (port difference) exceeds max loss delta value. Set related amplitude correction delta value to be lower than the max loss delta value given in error message.
-221	Settings conflict; Source List Step<n> MPA TX port<n> power setting <n>dBm is lower than -130dBm minimum	Indicating the power output setting (UI power + Amp Corr Value) on MPA TX port<n> on Source List Step<n> is lower than supportable minimum -130dBm. Set power output setting to be larger than -130dBm to eliminate this warning.
-221	Settings Conflict; Span limited to XXX	
-221	Settings conflict; Span Zoom is not available in Zero Span	Span Zoom does not work with a time domain x-axis. You must select a span greater than 0 Hz.
-221	Settings conflict; Step duration cannot be set to Play Count when the step is generating a CW tone	The you tried to set the source list step duration type to Play Count while the waveform of the step is CW. Play Count only applies to ARB.
-221	Settings conflict; Step keys are not available to modify this function	You should select a specific value for this function. So using the Up/Down step keys to scroll through values is not allowed.
-221	Settings conflict; Sweep Setup only available in swept measurements	The current measurement uses FFT mode and so does not use the Sweep Setup menu
-221	Settings conflict; Sweep Time cannot be auto-coupled in FFT sweeps	The sweep time for FFT sweeps is set by the calculations. So sweep time settings cannot be adjusted.
-221	Settings conflict; Sweep Time cannot be auto-coupled while in Zero Span	You cannot send the remote command to set the sweep time to auto while you are in zero span.
-221	Settings conflict; Sweep Time cannot be set while in FFT sweeps	The sweep time for FFT sweeps is set by the calculations. It cannot be manually controlled.
-221	Settings conflict; Swept IF Gain High not available when FFT IF Gain = Manual Low	When FFT IF Gain is manually set to Low, you cannot set the Swept IF Gain to High because that would make the Reference Level couplings wrong in swept mode.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Swept LO not available when freq mode is Fixed	SCPI only message. The LO Mode cannot be set to Swept when the freq mode is set to fixed. Change the freq mode away from fixed, or perform the measurement at several fixed frequencies.
-221	Settings conflict; Swept Type=Swept is not available while in Gated FFT	If you have selected gated FFT then you are using the FFT sweep type and you cannot select the swept type of sweeping.
-221	Settings conflict; System Display Settings, Annotation is Off	This is an override that turns off many of the annotations. This is available as a security feature.
-221	Settings conflict; T hot must be greater than T cold	The Tcold value set under Meas Setup/ENR/Tcold, needs to be lower than the Thot value currently being set. Tcold is often taken as the ambient temperature of the noise source. If using an SNS the Tcold value may be read automatically before every sweep.
-221	Settings Conflict; The parameter cannot be changed in FAST mode	
-221	Settings conflict; Time Domain Scan is not available with EMC "None" Standard	TDS only supports CISPR and MIL standards
-221	Settings conflict; Too many points; Stop Freq clipped to nearest value allowed	Range Stop Frequency has been clipped to the nearest value
-221	Settings conflict; Trace Math is not available while Normalize is on	The Normalize function works by doing trace manipulation, so trace math is not available while normalization is running.
-221	Settings conflict; Tracking Source unavailable in FFT Sweeps	Since FFT's do not sweep, you cannot use a Tracking Source while doing FFT's
-221	Settings conflict; Trigger input in use for source synchronization	If Point Trigger is being used with an external trigger input to synchronize an external source to the analyzer, that trigger input is unavailable for triggering.
-221	Settings conflict; Trigger is not available with span > 0 Hz.	
-221	Settings conflict; Tx Band Spur meas does not support this frequency band.	The transmit band spur measurement does not support all of the commercially available frequency bands. You need to change your selection under Mode Setup, Radio, Band to one of the supported bands.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Tx Band Spur measurement is not defined for mobiles.	Only base station testing is available.
-221	Settings conflict; X-Scale > 255 MHz unavailable in PvT	In the PvT window, X-Scale (Acq BW) cannot be greater than 255 MHz, even if Option B5X is installed.
-221	Settings conflict; Administrator privileges required	You must be logged in with administrator privileges to do this. Log out and log back in as the administrator, then restart the SA application.
-221	Settings conflict; Auto Scan Time/Meas Time do not apply in Stepped Scan Type.	The Auto Scan Time/Meas Time are not available when Scan Type =Stepped Scan.
-221	Settings conflict; Cannot accept time or count input when step duration type is Continuous on step #	An attempt to set list sequence some one step's "Duration Time" or "Play Count" when that step's "Duration Type" is "Continuous". This error can only occur on SCPI input. Set that step's "Duration Type" to "Play Count" or "Duration Time" first then setup count or time.
-221	Settings conflict; ClearList & Start not available when ScanSeq = (Re)measure	Cannot perform Clear List & Start during (Re)measure because we needs the frequency information of the peaks in signal list to perform (Re)measure.
-221	Settings conflict; Freq > 1 GHz is not available while RF Input 2 enabled	Frequency is limited to 1GHz while RF Input 2 is enabled.
-221	Settings conflict; Function not available while measurement is running	Settings change is not allowed while measurement is running. You must stop the current measurement if you wish to change the settings.
-221	Settings conflict; function unavailable with this EMC Standard	
-221	Settings conflict; Include Source is Yes. ARB memory operation is rejected	You tried to load or delete files to/from ARB memory in the Sequence Analyzer mode when Include Source is set to Yes. First set Include Source to No, then perform desired ARB memory operation.
-221	Settings conflict; Last screen cannot be deleted	There must be at least one Screen configured, you cannot delete the last remaining screen.
-221	Settings conflict; Log Percent Auto Step Rule does not apply in Swept Scan Type.	The Log Percent rule is not available when Scan Type=Swept Scan because we are always doing linear sweep.

Error Number	Message; Description	Verbose/Correction Information
-221	Settings conflict; Multi-Screen requires >1 screen	There must be more than one Screen configured for Multi-Screen to be enabled.
-221	Settings conflict; QPD + EMI Average + RMS Average is not allowed	User is not allowed to turn on all 3 EMI detectors together. You must turn off one of the EMI Detectors before you turn this on.
-221	Settings conflict; Range <{0}> is turned off as total range points > 4,000,001	Max of Total range points is 4,000,001. Reduce Scan Points or increase Step Size in order to turn on that range.
-221	Settings conflict; Scan Time & Points do not apply in current Step/Time Control.	The Scan Time & Points are not available when Step/Time Control is set to Step & Dwell.
-221	Settings conflict; Screen limit reached	You requested to add another screen with the number of screens at the maximum.
-221	Settings conflict; Screen SCPI cannot be used when Display is disabled	The instrument is operating with display disabled (DISPlay:ENABLE OFF), you cannot create new Screens with the display disabled.
-221	Settings conflict; Step Size & Meas Time do not apply in current Step/Time Control.	The Step Size & Meas Time are not available when Step/Time Control is set to Scan Time&Pts.
-221	Settings conflict; The number of input parameters is too large and is truncated to current list step number	An attempt to set list sequence parameter whose index exceeds the "Number of Steps". This way only those parameters whose indexes fall in number of steps will be accepted. Reduce the number of parameters to be no large than "Number of Steps".

-200 to -299, Execution Errors

This section lists all messages in the range *except* -221 messages. For details of -221 messages, see "[-221 Settings Conflict Errors](#)" on page 46.

Note that Execution Errors are divided into subclasses, as follows:

- 21x Trigger errors
- 22x Parameter error
- 23x Data corrupt or stale (invalid data)
- 24x Hardware error
- 25x Mass storage error

Instrument Messages
Event Messages

- 26x Expression data error
- 27x Macro error
- 28x Program error (a downloaded program-related execution error)
- 29x Memory use error

Error Number	Message; Description	Verbose/Correction Information
-200	All ranges are off. Turn on at least a range	There are no range turn on in scan table. You need to turn on at least a range to initiate a scan.
-200	At Full Zoom	Marker Zoom is not available as it has reached full zoom.
-200	Cannot move marker outside of displayed frequency span	Meters frequency is out of displayed frequency range. You must extend the displayed range from the scan table if you wish to set the selected marker to this frequency on the graph display.
-200	Disturbance List is Empty	Cannot perform the selected function because the disturbance list contains no data.
-200	Disturbance selected is not in the Disturbance List	The user has selected an invalid disturbance (one that is not in the list)
-200	Execution Error	A program execution error has occurred. The exact problem cannot be specifically identified.
-200	Execution error; Carrier frequency outside device's transmit band	The entered channel/carrier frequency is not within the range of your current mode setup selection of standard and device.
-200	Execution Error; Correction File Range x File x frequency out of range	You have tried to use correction file with frequencies that is out of range. Please fix the file or select another file.
-200	Execution error; Invalid GSM burst timing	A GSM-like burst was acquired, but its timing is not valid. Ensure the correct Burst Type has been selected.
-200	Execution error; Invalid IP address	The IP address supplied is either not valid or does not belong to a compatible Signal Generator. Please check the IP address and instrument connection and try again.
-200	Execution error; Invalid Marker Trace.	Cannot place markers on the reference trace, because the reference trace is currently turned off or has no data.
-200	Execution Error; No peak found.	No signal peak was found within the defined parameters of the search. (Note: for ESA/PSA compatibility, the Swept SA measurement uses 780 for this error number; all other measurements use -220)

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-200	Execution error; No ranges are defined. Activate a range.	There are no active ranges in the range table. You will need to activate at least one range.
-200	Execution Error; Preselector centering failed	Algorithm failed to center the preselector. This maybe caused by the signal peak being too low in amplitude. Or it could be from excessive CW input signal, alignment error, or hardware failure.
-200	Execution Error; Signal not stable enough to track	The signal that you have selected to track is changing too much for the function to track it properly.
-200	Execution Error; Store ref trace before turning on Normalize	The Reference trace data must be stored in the Ref trace before you turn on the Normalization function.
-200	Execution error; Sync word was not found.	NADC & PDC: In an EVM measurement, the sync word is not found and the synchronization cannot be established when Sync Word is selected in the Burst Sync menu. Flexible Digital Demodulation: The sync word cannot be detected because of inappropriate parameter settings or incorrect signal.
-200	Execution error; Trace file contains no compatible traces.	The trace file may have been created by another version of the Phase Noise personality, which uses a different trace format that is incompatible with the version you are running. Please check you are running the most up to date version of the personality.
-200	Execution error; Trace file created by incompatible version of Phase Noise App	The trace file may have been created by another version of the Phase Noise personality, which uses a different trace format that is incompatible with the version you are running. Please check you are running the most up to date version of the personality.
-200	Function not available before Marker Zoom is performed	Function not available before perform Marker Zoom
-200	Function not available before perform Disturbance Zoom	Need to zoom in before you can zoom out
-200	Function not available before Signal Zoom is performed	Function not available before Signal Zoom is performed.
-200	Must perform Scan before do Search	Cannot perform Search as the trace data is found empty
-200	No marked signal	Cannot perform the selected function because no signal was marked. You must mark the peak of interest before selecting the function.
-200	No Measure At Marker Added to Signal List	No signal peak was added into Signal List as there is no valid measure to Marker result. You must perform Measure at maker before selecting Measure At Marker --> List.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-200	No Peak Added to Signal List	No signal peak was added from the Search to Signal List as there is no signal peaks found within the defined parameters of the search criteria.
-200	No unmarked signals	Cannot perform the selected function because no signal was unmarked. You must unmark the peak of interest before selecting the function.
-200	Signal List is Empty	Cannot perform the selected function because the signal list contains no data.
-200	Signal List is Full	Cannot perform the selected function because the signal list is full. Please clear the list.
-200	Signal Selected is not in the Signal List	The signal selected is not the list. You only can perform the operation on signal that is already available in the list.
-200	Signal selected is out of display range	Signal selected is out of display range. You must extend the display range if you wish to view the selected signal on the graph display.
-201	Invalid while in local	The command cannot be executed while the instrument in Local control.
-202	Settings lost due to rtl	A "return to local" control was forced and some settings were lost as a result of this.
-203	Command protected	The command could not be executed because it is disabled. It was disabled by licensing or password protection
-203	Command protected; feature not licensed	The specified feature, for example "N9073A-TR2" is not licensed. The license may have expired. You cannot use it until you get a license.
-203	Command protected; Feature Not Supported. No appropriate waveform license installed for <filename>	An attempt was made to select a waveform while the required license is not installed Install necessary Signal Studio waveform licenses or multi-pack licenses.
-210	Trigger error	A trigger error has occurred, but the exact problem cannot be specifically identified.
-211	Trigger ignored	A GET, *TRG or other triggering signal was received, but it was ignored because of timing considerations. For example, maybe the instrument was not ready to respond when the command was received.
-212	Arm ignored	An arming signal was received, but it was ignored.
-213	Init ignored	An initiate trigger/sweep request was received and ignored, because another measurement was already in progress.
-214	Trigger deadlock	The trigger source for the initiation of a measurement is set to GET, and the following measurement query was received. The measurement cannot be started until a GET is received, but the GET would cause an INTERRUPTED error.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-215	Arm deadlock	The arm source for the initiation of a measurement is set to GET and the following measurement query is received. The measurement cannot be started until a GET is received and the GET would cause an INTERRUPTED error.
-220	Parameter error	A problem was found with a program data element. The exact problem cannot be specifically identified.
-220	Parameter error; <filename> is not loaded into ARB memory. Load the file before assigning to a multi-pack	An attempt was made to assign a multi-pack license to a waveform, while the waveform file has not been loaded into ARB memory. Load ARB into ARB memory first then add the ARB in multi-pack license slot.
-220	Parameter error; License slot <n> is illegal, slot number must be positive	An attempt was made to input a slot number less than or equals 0. Waveform slot number must be positive
-220	Parameter error; <filename> does not have a unique id, therefore cannot be assigned to a multi-pack	An attempt was made to add a Signal Studio waveform to a license slot while the waveformunique id is zero. Set the waveform unique ID to a value other than zero.
-220	Parameter error; Cannot create directory to save waveform sequence file. <error info>	An attempt was made to create a directory to store new waveform sequence but failed. Input correct directory path parameter.
-220	Parameter error; Cannot find the first waveform file <filename>	An attempt was made to build a new waveform sequence while the first specified waveform file is not found. Specify correct path for the first waveform segment.
-220	Parameter error; Invalid waveform sequence file path	An attempt was made to build or query a waveform sequence while the waveform sequence file path is invalid or not specified. Specify a correct path for the waveform sequence.
-220	Parameter error; License slot <n> is already locked	An attempted was made to lock a slot while the slot was already locked.
-220	Parameter error; License slot <n> is locked and cannot be cleared	An attempt was made to clear a slot while the slot was already locked.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-220	Parameter error; License slot <n> is locked, therefore cannot be replaced	An attempt was made to replace a slot with another waveform while the slot was already locked.
-220	Parameter error; License slot <n> is not assigned, therefore cannot be locked	An attempt was made to lock a slot while the slot was not assigned.
-220	Parameter error; Nested sequence file is not supported	An attempt was made to add a sequence file as a waveform segment into another sequence file.
-220	Parameter error; Nested sequence file is not supported	An attempt was made to build a new waveform sequence which contains another waveform sequence file. Do not nest waveform sequence file (*.seq) into another waveform sequence file (*.seq).
-220	Parameter error; No. <n> waveform file path is invalid	An attempt was made to build a new waveform sequence while the nth waveform file path is invalid or not specified. Specify a correct path for the waveform.
-220	Parameter error; Repetition value must be within 1 and 65535	An attempt was made to build a new waveform sequence with the repetition value set to less than 1 or greater than 65535.
-220	Parameter error; Sequence will be stuck on step <step number>. Next step trigger cannot be free run when current step duration is continuous	An attempt was made to set the current step duration to continuous, while the step trigger of the next step is set to free run. Make the next step trigger to be other than free run.
-220	Parameter error; Suffix of waveform sequence file should be “.seq”	An attempt was made to build a new waveform sequence while the suffix of waveform sequence file is not “.seq”. Ensure that the waveform sequence file suffix and file format is consistent with “seq”.
-220	Parameter error; Transition time is longer than duration time on step<step number>	An attempt was made to set the source step transition time to a value that is longer than step duration time, when the step duration type is “Time”. Make the transition time shorter than the duration time.
-220	Parameter error; Unrecognized marker type: <marker>	An attempt was made to build a new waveform sequence while the marker type value is invalid. Input correct maker type parameter.

Error Number	Message; Description	Verbose/Correction Information
-220	Parameter error; Waveform <filename> is already assigned to a waveform slot	An attempt was made to assign a waveform to a slot while the waveform was already assigned to another waveform slot.
-220	Parameter error; Waveform cannot be multi-pack licensed, no multi-pack slots available	An attempt was made to multi-pack license a waveform, but there are no free multi-pack license slots. Install multi-pack licenses to get multi-pack license slots.
-220	Parameter error; Waveform of that ID is already multi-pack licensed	An attempt was made to multi-pack license a waveform that was already licensed by a different multi-pack license slot.
-221	Settings conflict;	There are many types of settings conflict errors. For detailed information about these errors, see “-221 Settings Conflict Errors” on page 46 .
-222	Data out of range;	A data element was found but the instrument could not be set to that value because it was outside the range defined for the command. A descriptive message may be appended, such as “clipped to upper limit”
-222	Data out of Range; clipped to source max/min	A source parameter has been entered that exceeds the range of the selected source. The parameter has been clipped to match the range of the source
-222	Data out of Range; Dwell Time clipped to minimum value allowed	The dwell time entered could not be set to. It is clipped to the minimum allowable value, which is determined by the smallest RBW set in Scan Table.
-222	Data out of range; Invalid Correction Group range data	You tried to set the data for a Correction Group range which is not connecting to the range currently available.
-222	Data out of range; Invalid list data	You tried to use a trace that has a number of sweep points that is different from the current setting of sweep points.
-222	Data out of Range; Scan Time limited, multiple CISPR det’s in use for prescan	The scan time/ meas time entered could not be set to. Scan time is limited to 2.4 ks with multiple CISPR detectors turned on.
-222	Data out of Range; Step Size clipped to nearest value allowed	The step size entered could not be set to. It is clipped to the nearest allowable value.
-222	Data out of range; Two entries already exist at this x-axis value.	When entering values for limit lines, you cannot have more than two y-axis (amplitude) values entered for a specific x-axis (frequency) value.

Error Number	Message; Description	Verbose/Correction Information
-223	Too much data	A data element (of block, expression, array type, or string type) had more data than allowed by the command, or by the available memory.
-223	Too much data; 200 spurs found. Additional spurs ignored.	There are too many spurs for the table (the limit is 200), and any additional spurs that are found will be ignored.
-224	Illegal parameter value	An exact data value (from a list of the allowed values) was required - but not found. See the feature description for information about the expected parameter values.
-224	Illegal parameter value; <Value> invalid. Fractional values are not allowed.	The seconds parameter of an LXI time may not contain a fractional portion. For example 123456789.0 is valid while 123456789.1 is not.
-224	Illegal parameter value; <value> out of range.	The value does not fall in the valid range
-224	Illegal parameter value; Cannot set waveform to continue previous waveform on the first step	An attempt was made to set the waveform for the first step in a sequence to "Continue Previous" while there is no previous waveform to continue playing back.
-224	Illegal parameter value; Exceeding the max list length	The list parameters have a maximum allowed length. You are trying to set a length longer than the maximum.
-224	Illegal parameter value; existing Screen Name not found	An attempt was made to reference an existing Screen Name, but the text provided did not match an existing Screen Name.
-224	Illegal parameter value; Gated FFT is not available while Sweep Type is set to Swept	The gated FFT function is not available if you have selected the swept type of sweep. You must be in the FFT sweep type.
-224	Illegal parameter value; Gated LO is not available while Sweep Type is set to FFT	The FFT sweep type moves the LO frequency in steps. So the gated LO function is not available if you have selected FFT sweep.
-224	Illegal parameter value; Gated Video is not available while Sweep Type is set to FFT	The gated video function is not available if you have selected the FFT sweep type.

Error Number	Message; Description	Verbose/Correction Information
-224	Illegal parameter value; Index out of range	When querying the LXI Event Log or the Servo Log, an index may be used to look at a specific entry. This error occurs if the index provided does not point to a valid entry.
-224	Illegal parameter value; Invalid list length	You are trying to set some list measurement settings, but the multiple lists that you sent were not all the same length. The number of settings must be consistent from list to list.
-224	Illegal parameter value; Measurement not available	You tried to turn on a measurement that is not available in the current mode.
-224	Illegal parameter value; new Name already exists	An attempt was made to specify a new Name, but the name already exists; a unique name must be specified.
-224	Illegal parameter value; Res BW value not allowed with current Span	With Option B5X, with Spans greater than 255 MHz the Res BW desired is not available.
-224	Illegal parameter value; Cannot set waveform to continue previous waveform when previous step is set to CW or Off	An attempt was made to set the step duration for a step in a sequence to "Continue Previous", but the previous step was outputting a CW tone or is Off, so there is no waveform to continue.
-224	Illegal parameter value; Channel number is invalid for current band/link combination	An attempt was made to enter a channel number for a step within the List Sequencer, but the channel number is out of the valid range for the Band and Radio Band Link direction combination defined within the step.
-224	Illegal parameter value; This instrument is always DC coupled	You can't set AC coupling in this instrument
-224	Illegal parameter value; This model is always AC coupled	You can't set DC coupling in this analyzer
-225	Out of memory	There is not enough memory to perform the requested operation.
-225	Out of memory; Insufficient resources to load Mode <mode name>	If you attempt to load a mode via SCPI that will exceed memory capacity, the Mode does not load and this message is returned, where "mode name" is the SCPI parameter for the Mode in question, for example, "SA" for Spectrum Analyzer Mode. You can free up memory using the System, Power On, Configure Applications menu
-225	Out of memory; Memory limit caused Data Acquisition to be truncated	

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-226	List not same length	You are using the LIST structure, but have individual lists that are not the same lengths.
-230	Data corrupt or stale;	A legal data element was found, but it could not be used because the data format or the data structure was not correct. Maybe a new measurement had been started but had not completed.
-230	Data corrupt or stale; Measurement data is not available	Measurement data not available. The measurement that you are trying to get data from must be the current active measurement. Maybe you have not initiated the measurement, or it has not completed all the sweeps/averages needed.
-230	Data corrupt or stale; Trace contains no data.	Trace cannot be displayed because currently there is no data assigned to it. Use the functions under the Trace menu, or load a previously saved trace, to assign data to the trace.
-230	Data corrupt or stale; Unable to load state from file	There is something wrong with the state data in the desired file. Maybe the file is corrupt, or it is from an instrument/version that is not recognized by the current instrument.
-231	Data questionable	Indicates that the measurement accuracy is suspect
-232	Invalid format	A data element was found but it could not be used because the data format or the data structure was not correct.
-232	Invalid format; Map information not loaded	Instrument failed to load the burst mapping information from the selected file.
-232	Invalid format; <filename> contains invalid waveform header and cannot be loaded into ARB memory	An attempt was made to load, into ARB memory, a Signal Studio waveform file that contains an invalid waveform header.
-232	Invalid format; <filename> has less than 500 IQ samples	An attempt was made to load, into ARB memory, a waveform file, but the file does not contain enough IQ samples. Load an ARB waveform with a sample number equal to or greater than 500.
-232	Invalid format; Syntax error on source step <step number>	An attempt was made to load in a list sequencer file that was incorrectly formatted.
-232	Invalid format; Unable to open encrypted waveform file <filename>	An attempt was made to load, into ARB memory, a Signal Studio waveform file, but the file cannot be opened due to invalid file format.
-233	Invalid version	A legal data element was found but could not be used because the version of the data is incorrect. For example, state data changes as new instrument features are added, so old state files may not work in an instrument with a newer version of software.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-240	Hardware error	A legal program command or query could not be executed because of a hardware error. The exact problem cannot be specifically identified.
-240	Hardware error; See details in Windows Event Log under SA	The internal data acquisition system detected a problem at startup and logged the details in the Windows Event Log.
-241	Hardware missing	The operation could not be performed because of missing hardware; perhaps the optional hardware is not installed.
-241	Hardware missing; Input not available	The hardware required is not part of this model or the option is not installed
-241	Hardware missing; Internal preamp not available at all frequency points	The Internal Preamp is currently turned on, but the measurement is being performed completely or partially outside the range of the preamp. It is recommended that the user turns preamp off to ensure consistent results across the entire measurement.
-241	Hardware missing; not available for this model number	The hardware required is not part of this model
-241	Hardware missing; Option not installed	The optional hardware is not installed.
-250	Mass storage error;	A problem was found with the mass storage device (memory, disk drive, etc.). The exact problem cannot be specifically identified.
-250	Mass storage error; Access denied	Access is denied.
-250	Mass storage error; Bad path name	The specified path is invalid.
-250	Mass storage error; Can only import single trace .csv files	Trace files containing multiple traces can not be imported. However, if you need to recall multiple traces you can use the Save and Recall functions rather than the Import and Export functions.
-250	Mass storage error; Can only load an Antenna Unit into Correction 1	The only Correction register that supports Antenna Units is number 1. You have attempted to load an Ampcor file which contains antenna units into another register
-250	Mass storage error; Can only load one file with Antenna Unit per range	You already have a Correction file with Antenna Unit in this range. Attempt to import more than one Corrections file with Antenna Unit is not allowed.
-250	Mass storage error; Cannot make	The directory or file cannot be created.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-250	Mass storage error; Different Antenna Unit already in used in another range	You have attempted to import a Corrections file with Antenna Unit different from another range.
-250	Mass storage error; Different Antenna Unit already in use	Attempt to import Corrections file with Antenna Unit that differs from an in-use correction.
-250	Mass storage error; Directory not found	The system cannot find the path specified.
-250	Mass storage error; Failed to Load trace. Bad file format.	The load trace operation could not be completed, as the input file was not in the expected format. You can only load traces that were previously saved using the 'Save Trace' feature.
-250	Mass storage error; File <filename> wrong type	Attempt to import a data file that is not the proper type for this operation.
-250	Mass storage error; File <filename> and instrument version mismatch	While opening a file, there was a mismatch between file version or model number with instrument version or model number. The import still tried to load as much as possible, but you should check it closely.
-250	Mass storage error; File contains incorrect data for this operation	There is a mismatch between the file data type of the file specified and the destination indicated. For example, a correction set cannot be loaded/imported into a limit line.
-250	Mass storage error; File empty	Cannot save trace because it contains no data. Check that the trace is turned on and contains some valid data.
-250	Mass storage error; Invalid register number for *SAV or *RCL Mass Storage error	You have used the *SAV command to save a state to a non existent state register. Or You have used the *RCL command to recall a state register that wasn't previously saved with the *SAV command.
-250	Mass storage error; Lock violation	The process cannot access the file because another process has locked a portion of the file.
-250	Mass storage error; Mkr Table must be on to save Mkr Table as Meas Results	You have to have a Marker Table on the screen before you can save it. Turn on the Marker Table and try again.
-250	Mass storage error; No file names available	Attempt to use the auto file name generation when all 10,000 file names are taken.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-250	Mass storage error; Open failed	The system cannot open the device or file specified. This could be because the storage media is full, or possibly due to a filename error. If using an external storage device, check that the device is properly formatted.
-250	Mass storage error; Pk Table must be on to save Pk Table as Meas Results	You have to have a Peak Table on the screen before you can save it. Turn on the Peak Table and try again.
-250	Mass storage error; Read fault	The system cannot read from the specified device.
-250	Mass storage error; Register <number> empty	Attempt to recall a register with nothing in it
-250	Mass storage error; Sharing violation	The process cannot access the file because it is being used by another process.
-250	Mass storage error; Spectrogram must be on to save as Meas Results	You have to have a Spectrogram on the screen before you can save it. Turn on the Spectrogram and try again.
-250	Mass storage error; Too many open files	The system cannot open the file.
-250	Mass storage error; Write fault	The system cannot write to the specified device.
-250	Mass storage error; <directory> does not exist	An attempt was made to load all file from a directory while the specified directory does not exist on the instrument hard disk. Create the specified directory and then load the files or load the files using an existing directory.
-250	Mass storage error; <filename> cannot be deleted as it is currently in use	With ARB ON, an attempt was made to delete a waveform that was being played. Turn ARB to Off first, then delete ARB file from ARB memory.
-250	Mass storage error; <filename> cannot be deleted as it is used in sequencer	With the list sequencer state ON, an attempt was made to delete a waveform that was being used by the sequencer. First turn the List Sequencer to Off, then delete the ARB file from ARB memory.
-250	Mass storage error; <filename> used by sequencer is not in the ARB memory, cannot start sequencer	An attempt was made to start the sequencer without loading all of the needed waveform files into ARB memory. First load all necessary ARB files into ARB memory, then initiate the list sequence.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-250	Mass storage error; Create Directory Error: <directory> <err info>	An attempt was made to create a directory on the hard drive and failed.
-250	Mass storage error; Delete File Error: <filename> <err info>	An attempt was made to save data to an existing file and an error occurred deleting the old file.
-250	Mass storage error; Write File Error: <filename> <err info>	An attempt was made to save data to a file and an error occurred in writing the file.
-252	Missing media	A legal command or query could not be executed because missing media.
-253	Corrupt media	A removable media was found to be bad or incorrectly formatted. Any existing data on the media may have been lost.
-254	Media full	A legal command/query could not be executed because the media was full
-254	Media Full; <filename> cannot be loaded to ARB memory	The request to load a file to ARB memory failed because the ARB memory is full. OR An attempt was made to load a set of waveforms and there was insufficient free ARB memory to load all of the waveforms.
-255	Directory full	A legal command or query could not be executed because media directory was full.
-256	File name not found: <file name>	A waveform file was specified and was not found. OR A specified file is not at the specified location.
-256	File name not found;	A legal command or query could not be executed because the file name was not found in the specified location.
-257	File name error;	A legal command or query could not be executed because there was an error with the file name on the device media. For example, maybe you tried to copy to a duplicate file name.
-257	File name error; Allowable extension is .csv	You are using the wrong type of file extension for the current data/file type.
-257	File name error; Allowable extension is .png	You are using the wrong type of file extension for the current data/file type.
-257	File name error; Allowable extension is .state	You are using the wrong type of file extension for the current data/file type.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-257	File name error; Invalid file name	The filename, directory name, or volume label syntax is incorrect.
-257	File name error; name too long	
-257	File name error; <filename> contains unrecognized file suffix	An attempt was made to load or save a file with an unrecognized suffix. Ensure that the waveform file suffix and file format are consistent with one of: "bin", "waveform", "wfm" or "seq".
-257	File name error; Waveform file not selected	An attempted was made to turn the ARB player ON but a file has not been selected for playback. Select a waveform first, and then turn on ARB state.
-258	Media Protected	A legal command or query could not be executed because the media was protected. For example, the write-protect was set
-260	Expression error	An error was found with an expression type of data element. The exact problem cannot be specifically identified.
-261	Math error in expression	An expression that has legal syntax could not be executed because of a math error. For example, maybe you are dividing by zero.
-270	Macro error	Indicates that a macro-related execution error occurred.
-271	Macro syntax error	Indicates a syntax error within the macro definition
-272	Macro execution error	Indicates that a syntactically legal macro program data sequence could not be executed due to some error in the macro definition
-273	Illegal macro label	Indicates that the macro label defined in the *DMC command was a legal string syntax, but could not be accepted
-274	Macro parameter error	Indicates that the macro definition improperly used a macro parameter placeholder
-275	Macro definition too long	Indicates that a syntactically legal macro program data sequence could not be executed because the string or block contents were too long for the device to handle
-276	Macro recursion error	Indicates that a syntactically legal macro program data sequence could not be executed because the device found it to be recursive
-277	Macro redefinition\ not allowed	Indicates that a syntactically legal macro label in the *DMC command could not be executed because the macro label was already defined
-278	Macro header not found	Indicates that a syntactically legal macro label in the *GMC? query could not be executed because the header was not previously defined.
-280	Program error	There was an execution error in a down-loaded program. The exact problem cannot be specifically identified.
-281	Cannot create program	Indicates that an attempt to create a program was unsuccessful. A reason for the failure might include not enough memory.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-282	Illegal program name	The name used to reference a program was invalid; for example, redefining an existing program, deleting a nonexistent program, or in general, referencing a nonexistent program.
-283	Illegal variable name	An attempt was made to reference a nonexistent variable in a program.
-284	Program currently running	Certain operations dealing with programs may be illegal while the program is running; for example, deleting a running program might not be possible.
-285	Program syntax error	Indicates that a syntax error appears in a downloaded program. The syntax used when parsing the downloaded program is device-specific.
-286	Program runtime error	
-290	Memory use errors	
-291	Out of memory	
-292	Reference name does not exist; Waveform sequence contains an invalid waveform <filename>	A waveform sequence was selected for playback but not all of the waveform segments in the waveform sequence are loaded into ARB memory. Ensure that all of the waveform segments are loaded into the ARB memory.
-292	Referenced name does not exist	
-293	Referenced name already exists	
-294	Incompatible type	Indicates that the type or structure of a memory item is inadequate

-100 to -199, Command Errors

Error Number	Message; Description	Verbose/Correction Information
-100	Command error	There is a problem with the command. The exact problem cannot be specifically identified.
-101	Invalid character	An invalid character was found in part of the command.
-102	Syntax error	An unrecognized command or data type was found, for example a string was received for a command that doesn't accept strings.
-103	Invalid separator	The command was supposed to contain a separator but we found an illegal character. For example, the semicolon was omitted after a command string.
-104	Data type error	We found a data type different than what was expected. For example, numeric or string data was expected, but block data was found.
-105	GET not allowed	A Group Execute Trigger was received within a program message.
-108	Parameter not allowed	More parameters were received than were expected for the command. For example, the *ESE common command only accepts one parameter, so sending *ESE 0,1 is not allowed.
-109	Missing parameter	Fewer parameters were received than required for this command.
-110	Command header error	This is a general error that is generated when a problem is found in a command header, but we can't tell more specifically what the problem is
-111	Header separator error	We found an illegal character in a command where we expected to find a separator.
-112	Program mnemonic too long	The command contains a keyword that is more than twelve characters.
-113	Undefined header	The command meets the SCPI syntax requirements, but is not valid in the current measurement environment.
-114	Header suffix out of range	The value of a numeric suffix that is attached to a program mnemonic makes the header invalid. (A suffix is usually units, like Hz or DB.)
-115	Unexpected number of parameters	The number of parameters received does not correspond to the number of parameters expected.
-120	Numeric data error	An error was found in a data element that appears to be numeric. The exact problem cannot be specifically identified.
-121	Invalid character in number	A character was found that is not valid for the data type. For example, an alpha in a decimal numeric or a "9" in octal data.
-123	Exponent too large	The magnitude of an exponent was greater than 32000.
-124	Too many digits	The mantissa of a decimal-numeric contained more than 255 digits, excluding leading zeros.
-128	Numeric data not allowed	A legal numeric data element was found, but that is not a valid element at this position in the command.

Error Number	Message; Description	Verbose/Correction Information
-130	Suffix error	A problem was found in a suffix (units). The exact problem cannot be specifically identified.
-131	Invalid suffix	There is a syntax problem with the suffix. You need to use the suffix (units) that are allowed by this command.
-134	Suffix too long	The suffix contained more than twelve characters.
-138	Suffix not allowed	A suffix was found after a numeric element that does not allow suffixes (units).
-140	Character data error	A problem was found with a character data element. The exact problem cannot be specifically identified.
-141	Invalid character data	Either the character data element contains an invalid character or the element itself is not valid for this command.
-144	Character data too long	The character data element contains more than twelve characters.
-148	Character data not allowed	A character data element that you sent is valid, but it is not allowed in this point in the parsing.
-150	String data error	A problem was found with a string data element. The exact problem cannot be specifically identified.
-151	Invalid string data	A string type of data element was expected, but it is invalid for some reason. For example, an END message was received before the terminal quote character.
-158	String data not allowed	A string data element that you sent is valid, but it is not allowed at this point in the parsing.
-160	Block data error	A problem was found with a block data element. The exact problem cannot be specifically identified.
-161	Invalid block data	A block data element was expected, but it was invalid. For example, an END message was received before the end length was satisfied.
-168	Block data not allowed	A legal block data element was found, but it is not allowed at this point in the parsing.
-170	Expression error	A problem was found with an expression data element. The exact problem cannot be specifically identified.
-171	Invalid expression	An expression data element is not valid. For example, there may be unmatched parentheses or an illegal character.
-178	Expression data not allowed	A legal expression data was found, but it is not allowed at this point in the parsing.
-180	Macro error	A problem was found with a macro element. The exact problem cannot be specifically identified.
-181	Invalid outside macro definition	Indicates that a macro parameter placeholder was encountered outside of a macro definition.

Instrument Messages
Event Messages

Error Number	Message; Description	Verbose/Correction Information
-183	Invalid inside macro definition	Indicates that the program message unit sequence, sent with a *DDT or *DMC command, is syntactically invalid
-184	Macro parameter error	Indicates that a command inside the macro definition had the wrong number or type of parameters.

0 No Error

Error Number	Message; Description	Verbose/Correction Information
0	No error	The queue is empty. Either every error in the queue has been read, or the queue was cleared by power-on or *CLS.

Condition Messages

Condition messages are classified as either “Errors” or “Warnings.” Condition messages are **not** defined in the [1999 SCPI Syntax & Style Standard](#), and have numbers greater than zero.

Every Condition has an associated Detected (Start) Event and Cleared (End) Event. The Condition itself has the same number as its Detected Event. The Detected Event has a number less than 1000, and the Cleared Event has the same number plus 1000.

In the tables in this section, an E in the Error or Warning column means that an Error is displayed on the front panel and sent out to SCPI when this condition is detected. A W in this column means that a Warning is displayed on the front panel, but nothing is sent to SCPI.

For each Condition Message, there is a corresponding bit in one of the SCPI status registers. These bits are listed in the “Bit in status register” column of the tables below. Some messages exist **only** as status bits; for these messages the Error or Warning column contains “status bit only”.

The tables in this section are divided by number range, as follows:

- [“1 to 99, Calibration” on page 82](#)
- [“101 to 199, Measurement Integrity” on page 87](#)
- [“201 to 299, Signal Integrity” on page 92](#)
- [“301 to 399, Uncalibrated Integrity” on page 97](#)
- [“401 to 499, Power” on page 100](#)
- [“501 to 599, Frequency” on page 101](#)
- [“601 to 699, Error Summaries” on page 102](#)
- [“701 to 799, Operation” on page 104](#)
- [“801 to 899, Temperature” on page 105](#)

1 to 99, Calibration

These messages correspond to the `STATUS:QUESTIONABLE:CALIBRATION` register (see [“X-Series Status Register System” on page 109](#)). Since this register is fanned out to three sub-registers, with summary bits in the main `STATUS:QUESTIONABLE:CALIBRATION` register, each sub-register has its own range of message numbers.

6 to 34, Calibration Skipped

This series of messages corresponds to the bits in the `STATUS:QUESTIONABLE:CALIBRATION:SKIPPED` sub-register (see [“X-Series Status Register System” on page 109](#)). The second column in the table shows the corresponding bit in that register.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the number plus 1000 is generated. These numbers can be viewed in the Show Errors screen, along with the DETECTED and CLEARED indicators.

For example, message 6 indicates that the “RF Alignment being skipped” condition has been detected, and message 1006 indicates that failure has been cleared.

This register is summarized as bit 11 of the `STATUS:QUESTIONABLE:CALIBRATION` register, as described in section “36 to 64, Calibration Needed or Failed” on page 83.

Msg#	Bit in status register	Message	Error or Warning	More Information
6	0	Align RF Skipped	W	
8	1	unused		
10	2	unused		
12	3	unused		
14	4	unused		
16	5	unused		
18	6	unused		
20	7	unused		
22	8	unused		
24	9	unused		
26	10	unused		
28	11	unused		
30	12	unused		
32	13	unused		
34	14	unused		

36 to 64, Calibration Needed or Failed

This series of messages corresponds to the bits in the `STATUS:QUESTIONABLE:CALIBRATION` register (see “X-Series Status Register System” on page 109). The second column in the table shows the corresponding bit in that register.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the number plus 1000 is generated. These error numbers can be viewed in the Show Errors screen, along with the DETECTED and CLEARED indicators.

For example, message 42 indicates that the “RF Alignment Failure” condition has been detected, and message 1042 indicates that failure has been cleared.

Several bits in this register are “summary bits” for registers at a lower level. There are no messages associated with these bits; they exist only as status bits, which can be read with a `STATUS:QUESTIONABLE:CALIBRATION?` event query or a `STATUS:QUESTIONABLE:CALIBRATION:CONDITION?` query.

Note that these summary bits summarize the state and history of the event registers at the lower level. This is true even for bits in the `STATUS:QUESTIONABLE:CALIBRATION` condition register. This means that:

- The summary bits read by the `STATUS:QUESTIONABLE:CALIBRATION:CONDITION?` query are true if any event bits are set in any of the `:CALIBRATION` sub-registers `:SKIPPED`, `:EXTENDED:NEEDED` or `:EXTENDED:FAILURE`.
- The summary bits read by the `STATUS:QUESTIONABLE:CALIBRATION?` event query are true if any event bit has undergone a false-to-true transition with the `PTRANSITION` filter set, or a true-to-false transition with the `NTRANSITION` filter set, in any of the `:CALIBRATION` sub-registers `:SKIPPED`, `:EXTENDED:NEEDED` or `:EXTENDED:FAILURE`.

Thus, the summary bits **cannot** be used to determine the current state of a lower level condition bit; only the state and history of the lower level event bits.

This register is itself summarized as bit 8 of the `STATUS:QUESTIONABLE` register, as described in the section “601 to 699, Error Summaries” on page 102.

Msg#	Bit in status register	Message	Error or Warning	More Information
36	0	unused		
38	1	unused		
40	2	TG Alignment Failure	E	
42	3	RF Alignment Failure	E	
44	4	IF Alignment Failure	E	
46	5	LO Alignment Failure	E	
48	6	ADC Alignment Failure	E	
50	7	FM Demod Alignment Failure	E	

Msg#	Bit in status register	Message	Error or Warning	More Information
52	8	Extended Align Needed Summary	status bit only	This bit is the summary bit for the STATUS:QUESTIONABLE:CALIBRATION:EXTENDED:NEEDED sub-register.
54	9	Extended Align Failure Summary	status bit only	This bit is the summary bit for the STATUS:QUESTIONABLE:CALIBRATION:EXTENDED:FAILURE sub-register.
56	10	unused		
58	11	Align Skipped Sum Summary	status bit only	This bit is the summary bit for the STATUS:QUESTIONABLE:CALIBRATION:SKIPPED sub-register.
60	12	Align Now, RF required	E	
62	13	unused		
64	14	Align Now, All required	E	On PSA, this was error 64

65 to 92, Calibration Needed (Extended)

This series of messages corresponds to the bits in the STATUS:QUESTIONABLE:CALIBRATION:EXTENDED:NEEDED sub-register (see [“X-Series Status Register System” on page 109](#)). The second column in the table below shows the corresponding bit in that register.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the number plus 1000 is generated. These error numbers can be viewed in the Show Errors screen, along with the DETECTED and CLEARED indicators.

For example, message 72 indicates that the “Input Attenuation not calibrated” condition has been detected, and message 1072 indicates that failure has been cleared.

This register is summarized as bit 8 of the STATUS:QUESTIONABLE:CALIBRATION register, as described in the section [“36 to 64, Calibration Needed or Failed” on page 83](#).

Msg#	Bit in status register	Message	Error or Warning	More Information
65	0	unused		
66	1	Align 9kHz–30MHz required	E	An EMI conducted frequency range alignment is needed.
68	2	Align 30MHz–1GHz required	E	An EMI radiated frequency range alignment is needed.

Msg#	Bit in status register	Message	Error or Warning	More Information
	3			
72	4	Input Attenuation not calibrated	E	Corrected measurements have been requested and the required RF front-end setting of x dB has not been calibrated.
74	5	unused		
76	6	unused		
78	7	unused		
80	8	MPA Align required	W	EXT only
82	9	unused		
84	10	unused		
86	11	Characterize Preselector required	W	Align
88	12	Characterize Noise Floor required	W	
90	13	unused		
92	14	unused		

67 to 95, Calibration Failure (Extended)

This series of messages corresponds to the bits in the `STATUS:QUESTIONABLE:CALIBRATION:EXTENDED:FAILURE` sub-register (see [“X-Series Status Register System” on page 109](#)). The second column in the table shows the corresponding bit in that register.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the error number plus 1000 is generated. These numbers can be viewed in the Show Errors screen, along with the DETECTED and CLEARED indicators.

For example, error 71 indicates that the Characterize Preselector Failure has been detected, error 1071 indicates that failure has been cleared.

This register is summarized as bit 9 of the `STATUS:QUESTIONABLE:CALIBRATION` register, as described in the section [“36 to 64, Calibration Needed or Failed” on page 83](#).

Msg#	Bit in status register	Message	Error or Warning	More Information
67	0	Align 9kHz to 30MHz failed	W	On PSA, this was error 13749
69	1	Align 30MHz to 1GHz failed	W	On PSA, this was error 13751
71	2	Characterize Preselector failure	W	The preselector characterization routine failed.
73	3	unused		
75	4	unused		
77	5	unused		
79	6	Align Source IQ failed	W	EXT only
81	7	Align Source RF failed	W	EXT only
83	8	MPA Align failed	W	EXT only
85	9	unused		
87	10	unused		
89	11	unused		
91	12	unused		
93	13	unused		
95	14	unused		

101 to 199, Measurement Integrity

This series of messages corresponds to the bits in the `STATUS:QUESTIONABLE:INTEGRITY` register (see [“X-Series Status Register System” on page 109](#)). The second column in the table shows the corresponding bit in that register.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the number plus 1000 is generated. These error numbers can be viewed in the Show Errors screen, along with the DETECTED and CLEARED indicators.

For example, message 141 indicates an Input Overload condition has been detected, message 1141 indicates that failure has been cleared.

Two bits in this register are “summary bits” for registers at a lower level. There are no error messages associated with these bits; they exist only as status bits, which can be read with a `STATUS:QUESTIONABLE:INTEGRITY?` event query or a `STATUS:QUESTIONABLE:INTEGRITY:CONDITION?` query.

Note that these summary bits summarize the state and history of the event registers at the lower level. This is true even for bits in the `STATUS:QUESTIONABLE:INTEGRITY` condition register. This means that:

- The summary bits read by the `STATUS:QUESTIONABLE:INTEGRITY:CONDITION?` query are true if any event bits are set in any of the `:INTEGRITY` sub-registers `:SIGNAL` or `:UNCALIBRATED`.
- The summary bits read by the `STATUS:QUESTIONABLE:INTEGRITY?` event query are true if any event bit has undergone a false-to-true transition with the `PTRANSITION` filter set, or a true-to-false transition with the `NTRANSITION` filter set, in any of the `:INTEGRITY` sub-registers `:SIGNAL` or `:UNCALIBRATED`.

Thus, the summary bits **cannot** be used to determine the current state of a lower level condition bit; only the state and history of the lower level event bits.

This register is itself summarized as bit 9 of the `STATUS:QUESTIONABLE` register, as described in the section “601 to 699, Error Summaries” on page 102.

Msg#	Bit in status register	Message; Description	Error or Warning	More Information
133	0	Signal Summary	status bit only	This bit is the summary bit for the <code>STATUS:QUESTIONABLE:INTEGRITY:SIGNAL</code> sub-register.
135	1	No Result	E	
135	1	No Result; Turn on MCE	E	To calculate Timing and Phase results in the Code Domain Power view of Mod Accuracy, the "Multi Channel Estimator" must be set to ON. Otherwise these results are invalid.
135	1	No Result; Meas invalid with I/Q inputs	E	The current measurement does not support I/Q input; switch to the RF or another input or select a different measurement
135	1	No Result; Meas/Radio Std incompatibility	E	The current measurement is incompatible with the current Radio Standard; change Radio Standard to use this measurement
137	2	unused		

Instrument Messages
Condition Messages

Msg#	Bit in status register	Message; Description	Error or Warning	More Information
139	3	Uncalibrated Summary	status bit only	This bit is the summary bit for the STATUS:QUESTIONABLE:INTEGRITY:UNCALIBRATED sub-register.
141	4	Input Overload	E ^a	
141	4	Input Overload; ADC over range	E ^a	The signal at the input to the IF section is too high. You should increase the attenuation or lower the signal level.
141	4	Input Overload; I/Q ADC over range	E ^a	The I or Q input exceeds the ADC upper limit.
141	4	Input Overload; I/Q Voltage over range	E ^a	The input voltage on the I or Q channel exceeds the channel limit. In differential mode the over voltage may occur without causing an ADC overload, for example, if I is at +5.01 V and I-bar is at +5.0 the ADC will be in range but both I and I-bar will exceed the voltage limit.
141	4	Input Overload; RF Preselector Overload	E ^a	The level at the input of the MXE RF Preselector has exceeded tolerances, reduce the input level
143	5	unused		
145	6	unused		
147	7	Insufficient Data	E	
147	7	Insufficient Data; Incr. Demod Time	E	There is insufficient acquisition data to provide accurate metrics. You should increase the Demod Time to acquire enough data.
147	7	Insufficient Data; frequency list empty	E	A measurement was attempted with List frequency mode or a SCPI query of the frequency list table was made and the frequency list table is empty.
147	7	Insufficient Data; ENR table empty	E	A measurement was attempted or a SCPI query of an ENR table was made and there were no entries in the relevant ENR table (Common, Meas or Cal).
147	7	Insufficient Data; Loss table empty	E	A measurement is attempted or a SCPI query of a before or after loss table is made and there are no entries in the relevant loss table

Instrument Messages
Condition Messages

Msg#	Bit in status register	Message; Description	Error or Warning	More Information
149	8	Meas Error		
151	9	Memory Error	E	
151	9	Memory Error; Shorten capture interval	E	A shortage of free memory related to longer capture intervals has occurred. The measurement is aborted and all results return invalid values
153	10	I/O Error	E	
153	10	I/O Error; Ext Source needs IP Addr	E	No IP address entered for external source and external LO control is ON.
155	11	Trig Error	E	
157	12	Invalid Data	Status bit only	This is the "invalid data indicator", same as the "*" in the upper right corner of the screen. It means that the on-screen annotation does not match the on-screen data, usually because a measurement is pending after a settings change. There is no message in the status line and nothing in the history queue, but there IS an on-screen indication and a status bit.
159	13	Settings Alert	W	
159	13	Settings Alert; LO may overload IF	W	If the sweep type is Swept, the start frequency of the instrument is less than 10 MHz, and you put Swept IF Gain in Manual High, then a warning condition is generated and remains in effect as long as this condition exists. In some older analyzers this was error 1109.
159	13	Settings Alert; Diff probe mismatch; <I Q I,Q>	W	The attenuation values of the two probes on the I and/or Q channels differ by too much for a valid differential reading.

Instrument Messages
Condition Messages

Msg#	Bit in status register	Message; Description	Error or Warning	More Information
159	13	Settings Alert; Acquisition truncated	W	In the Analog Demod mode, certain extreme settings combinations will result in a required acquisition length in excess of the capacity of the analyzer. Increase the AF Spectrum RBW or the RF Spectrum RBW, decrease the Channel BW, and/or decrease the Demod Waveform Sweep Time.
159	13	Settings Alert; Analog Out settings conflict	W	The user has manually set the Analog Output under the Input/Output menu to a setting that conflicts with the current measurement. There will be no output on the Analog Out port until this conflict is resolved. In most cases, simply set Analog Out to Auto for the optimal setting.
159	13	Settings Alert; I/Q mismatch:<Differential Input Z Attenuation>	W	The impedance, differential, or attenuation settings for the I and Q channels do not match. For valid I+jQ measurements the impedance and differential settings should be the same on both channels and the attenuation should match within 1 dB
159	13	Settings Alert; Parm/data mismatch	W	For Bluetooth, the detected parameters did not match the data
159	13	Settings Alert; Src pwr ramp>ALC range	W	You have chosen a Power Sweep range that exceeds the ability of the external Source to follow without changing mechanical attenuation. Lower your Power Sweep range.
159	13	Settings Alert; Sweep Rate Unavailable	W	The auto coupled sweep time exceeds the maximum allowed. Therefore, full amplitude accuracy cannot be attained. Please increase the RBW or reduce the span.
159	13	Settings Alert; Span:RBW Ratio too big	W	The chosen large ratio of span to RBW is not possible. Please reduce the span or increase the RBW and/or FFT Width.

Msg#	Bit in status register	Message; Description	Error or Warning	More Information
159	13	Settings Alert; Freq>USB Preamp max	W	The highest analysis frequency exceeds the frequency range of the USB preamp used. In Noise Figure measurement applications, this situation will cause gradual degradation of uncertainty with increasing frequency. In Spectrum Analyzer applications, this will cause rapidly declining amplitude accuracy with increasing frequency.
161	14	Setting Modified	E	
161	14	Setting Modified; Filter not applied	E	The filter you have selected is larger than the sampling frequency. You should select a different filter.

- a. The Input Overload error is not reported to the SCPI queue unless the :SYS-Tem:ERROR:OVERload ON command has been issued, however it always sets the status bit.

201 to 299, Signal Integrity

This series of messages corresponds to the bits in the `STATUS:QUESTIONable:INTEgrity:SIGNal` sub-register (see “X-Series Status Register System” on page 109). The second column in the table shows the corresponding bit in that register.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the number plus 1000 is generated. These error numbers can be viewed in the Show Errors screen, along with the DETECTED and CLEARED indicators.

For example, message 207 indicates a Burst Not Found condition has been detected, message 1207 indicates that failure has been cleared.

This register is summarized as bit 0 of the `STATUS:QUESTIONable:INTEgrity` register, as described in the section “101 to 199, Measurement Integrity” on page 87.

Msg#	Bit in Status Register	Message; Description	Error or Warning	More Information
203	0	unused	E	
205	1	unused	E	

Instrument Messages
Condition Messages

Msg#	Bit in Status Register	Message; Description	Error or Warning	More Information
207	2	Burst Not Found	E	<p>The burst signal cannot be detected because of inappropriate parameter settings or incorrect signal.</p> <p>An in appropriate parameter setting could cause the signal to be partially, rather than fully, on the display, Burst Search Threshold and/or Burst Search Length may need to be adjusted.</p> <p>An incorrect signal could have either insufficient power, the rising or falling edges cannot be detected, or the burst is less than 126 microseconds.</p> <p>Carrier signal is not actually bursted.</p> <p>This message may have a Mode-dependent interpretation:</p> <p>W-CDMA: Either the signal being analyzed has insufficient power, the rising or falling edges cannot be detected, or the burst is less than 126 microseconds.</p> <p>W-CDMA: Cannot synchronize measurement with PRACH channel for Power Control measurement, because the signal cannot be found. Make sure PRACH is present in the W-CDMA uplink signal, and that the preamble signature and scramble code are set correctly.</p> <p>GSM: Data was acquired but a GSM burst was not found, with the timeslot mode disabled.</p> <p>NADC, PDC: A valid burst is not found when the Device is MS.</p> <p>1xEV-DO: Data was acquired but a 1xEV burst was not found, with the timeslot mode disabled.</p> <p>Bluetooth: The burst that has been found does not correspond to the currently selected Bluetooth packet type (the burst length may be too short).</p> <p>WLAN: The instrument cannot find a valid WLAN burst. You may need to extend the search length.</p> <p>In the PSA, this error was reported as one of the following error numbers: 10772, 13104, 10160, 10286, 10420, 10454, 10614, 10904, 10928, 13074, 10287</p>

Instrument Messages
Condition Messages

Msg#	Bit in Status Register	Message; Description	Error or Warning	More Information
207	2	Burst not found; with selected Time Slot	E	The selected timeslot does not contain the expected burst.
209	3	Timing Error	E	
209	3	Timing Error: No time ref pilot burst	E	The pilot burst used for time reference is not active.
211	4	Carrier(s) incorrect or missing	E	In the PSA, this error was reported as one of the following error numbers: 10165, 10173, 10178, 10419, 10421, 10535, 10560, 10642, 10648, 10650, 10960
213	5	Freq Out of Range	E	
213	5	Freq Out of Range; System input (IF)	E	One or more system input frequencies are out of range. If using a frequency list, check that all entries are valid for current measurement mode.
213	5	Freq Out of Range; External LO	E	One or more external LO frequencies are out of range. Check that the LO frequency limits are set correctly and check the entered measurement frequencies and measurement mode.
215	6	Sync Error	E	W-CDMA Mode: Cannot sync DPCCH pilot. Cannot synchronize measurement with DPCCH pilot for Power Control measurement, because the pilot signal cannot be found. Make sure DPCCH is present in the W-CDMA uplink signal, and that the slot format and scramble code are set correctly.
215	6	Sync Error; No pilot burst	E	There is no Pilot burst detected.
215	6	Sync Error; Sync code not found	E	Synchronization code is not found in the measured time slot.
215	6	Sync Error; No freq ref pilot burst	E	The pilot burst used for frequency reference is not active.
215	6	Sync Error; Midamble sync fail	E	Failed to find the uplink slot, which caused the synchronization with the midamble to fail.
215	6	Sync Error; Preamble length zero	E	Burst type is "Data" or "Preamble" and the measurement cannot find a Preamble

Instrument Messages
Condition Messages

Msg#	Bit in Status Register	Message; Description	Error or Warning	More Information
217	7	Demod Error	E	<p>This error is normally generated for one of the following reasons:</p> <ol style="list-style-type: none"> 1. There is no carrier signal. 2. Walsh channels other than the pilot are active. 3. There is some other modulation problem that will prevent the measurement from being made. <p>This problem must be corrected before the measurement can continue.</p> <p>This message may have a Mode-dependent interpretation:</p> <p>cdma 2000 & W-CDMA: Cannot correlate to the input signal and no active channel is found. (from composite EVM measurement) An active channel must meet the default threshold criteria that it is within 20 dB of the highest power code channel. The threshold can be changed using the active set threshold function in the Meas Setup menu.</p> <p>cdmaOne: A correlation failure with the pilot CDMA channel occurred during synchronous demodulation.</p> <p>1xEV-DO: Cannot correlate to the input signal and no active channel is found. (from composite EVM measurement) An active channel must meet the default threshold criteria that it is within 20 dB of the highest power code channel. The threshold can be changed using the active set threshold function in the Meas Setup menu.</p> <p>In the PSA, this error was reported as one of the following error numbers: 10872, 10962, 13070, 10228, 10768</p>
217	7	Demod Error; Can't correlate	E	<p>Cannot correlate to the input signal and no active channel is found. (from composite EVM measurement) An active channel must meet the default threshold criteria that it is within 20 dB of the highest power code channel. The threshold can be changed using the active set threshold function in the Meas Setup menu.</p>

Instrument Messages
Condition Messages

Msg#	Bit in Status Register	Message; Description	Error or Warning	More Information
217	7	Demod Error; Data interval too short	E	There are not enough input I/Q pairs for the measurement calculation. This may be caused by an incorrect data capture.
217	7	Demod Error; No active channel	E	There is no active channel detected.
217	7	Demod Error; Not an active slot	E	There is no active slot detected.
217	7	Demod Error; No full subframe found	E	No sub-frame or only part of one sub-frame is detected.
217	7	Demod Error; Muxed bits not found	E	Multiplexed Data Demod Bits are not generated even though Data channel is selected, because all 16 data code channels are not active
217	7	Demod Error; Acq Time too short	E	Bluetooth Mode: The detected packet type doesn't match the captured packet type because the payload start, end or data could not be found.
219	8	Signal Too Noisy	E	This message may have a Mode-dependent interpretation: NADC & PDC: The valid EVM measurement cannot be performed, because the input signal is too noisy. GSM & EDGE: In a GSM measurement, indicates that a burst could not be found in a signal that appears noisy. In the PSA, this error was reported as one of the following error numbers: 10702, 10824, 10906, 10930, 13024, 10626, 111
221	9	Slot Error	E	
221	9	Slot error; No active slot found	E	No valid active slot found in captured data, or no active slot found in captured interval. Synchronization may succeed and pilot found when this message is issued, but no results are included in peak/average calculation.
221	9	Slot Error; No idle slot found	E	No valid idle slot found in captured data, or no idle slot found in captured interval. Synchronization may succeed and pilot found when this message is issued, but no results are included in peak/average calculation.
223	10	unused	E	

Msg#	Bit in Status Register	Message; Description	Error or Warning	More Information
225	11	unused	E	
227	12	unused	E	
229	13	unused	E	
231	14	unused	E	

301 to 399, Uncalibrated Integrity

This series of messages corresponds to the bits in the `STATUS:QUESTIONABLE:INTEGRITY:UNCALIBRATED` sub-register (see [“X-Series Status Register System” on page 109](#)). The second column in the table shows the corresponding bit in that register.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the number plus 1000 is generated. These error numbers can be viewed in the Show Errors screen, along with the DETECTED and CLEARED indicators.

For example, message 301 indicates a Meas Uncal condition has been detected, message 1301 indicates that failure has been cleared.

This register is summarized as bit 3 of the `STATUS:QUESTIONABLE:INTEGRITY` register, as described in the section [“101 to 199, Measurement Integrity” on page 87](#).

Msg#	Status Register Bit	Message; Description	Error or Warning	Verbose/Correction Information
301	0	Meas Uncal	W	
303	1	Signal ID on	W	
305	2	No Long Code Phase	W	
307	3	AC coupled: Accy unspec'd <10 MHz	W	AC input coupling will function at lower frequencies, but the performance is not specified below 10 MHz.
309	4	User cal	W	

Instrument Messages
Condition Messages

Msg#	Status Register Bit	Message; Description	Error or Warning	Verbose/Correction Information
309	4	User Cal; Cal invalidated	E,W	<p>The existing user cal has been invalidated for one of the following reasons:</p> <p>Frequency: Setting the frequency outside the current valid user cal set (for example: If the current sweep range is 2 to 3GHz, then setting the start frequency to 1.9 GHz will invalidate the current user cal. Other frequency changes that will invalidate the user cal are:</p> <ul style="list-style-type: none"> – If the cal was performed at a fixed frequency and you change this frequency. – If you are in "Freq List" mode and you change it to extend beyond the current user cal range. In this case you will see an error message. <p>DUT Type: If the DUT Type parameter changes, causing the measurement frequencies to be pushed outside the current cal.</p> <p>Attenuation: If an attenuation setting is selected but has not been calibrated.</p> <p>Preamp: If set to condition different from current cal settings, for example: if calibrated with the preamp on, turning it off will invalidate the cal.</p> <p>Points: Changing the number of measured frequency points can make the stored preselector offsets become inaccurate and hence invalidate the calibration. This occurs when the following conditions exist:</p> <ul style="list-style-type: none"> – A successful calibration has been performed. – Some measured freq points are > 3.6 GHz. – The new points > 3.6 GHz are located more than 50 MHz away from the current calibration points.

Instrument Messages
Condition Messages

Msg#	Status Register Bit	Message; Description	Error or Warning	Verbose/Correction Information
309	4	User Cal; Freq outside cal range	E	The existing user cal has been invalidated because the current measurement frequencies lie partially or wholly outside the range of frequencies used for user-cal. (UNCAL)
309	4	User Cal; Cal will be interpolated	W	The measurement frequency range has been changed such that it is a subset of the calibrated range. (~CAL)
309	4	User Cal; Adjusted for new RBW	W	The measurement RBW has been changed since the last calibration (~CAL)
311	5	Calibration	W	
311	5	Calibration; ENR table extrapolated	W	One or more calibration or measurement frequency points exceed the currently loaded Cal or Meas ENR Table frequency ranges. The corresponding ENR table's lowest frequency ENR value will be re-used for frequencies less than the table range, and the highest frequency ENR value will be re-used for frequencies greater than the table range. (~ENR)
311	5	Calibration; No ENR data present	W	No ENR Data (ENR)
313	6	Source Uncal	W	
313	6	Source Uncal; adj Start Freq or RBW	W	While using a Tracking Source, you must make sure the Start Frequency is high enough to avoid capturing LO feedthrough in the trace. This depends on both Start Freq and RBW. If you get this message, increase your Start Freq or narrow your RBW.
313	6	Source Uncal; adjust Source Amplitude	W	While using a Tracking Source, source amplitude can be set at specific uncalibrated range, but the performance is not specified. If you get this message, adjust source amplitude.
315	7	Preamp: Accy unspec'd <XX kHz	W	Preamp will function at lower frequencies, but the performance is not specified below XX kHz (XX is model number specific).

Msg#	Status Register Bit	Message; Description	Error or Warning	Verbose/Correction Information
317	8	unused	W	
319	9	unused	W	
321	10	unused	W	
323	11	unused	W	
325	12	unused	W	
327	13	unused	W	
329	14	unused	W	

401 to 499, Power

This series of messages corresponds to the bits in the `STATUS:QUESTIONABLE:POWER` register (see [“X-Series Status Register System” on page 109](#)). The second column in the table shows the corresponding bit in that register.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the number plus 1000 is generated. These error numbers can be viewed in the Show Errors screen, along with the DETECTED and CLEARED indicators.

For example, message 409 indicates a 50 MHz Oscillator Unleveled condition has been detected, message 1409 indicates that failure has been cleared.

This register is summarized as bit 3 of the `STATUS:QUESTIONABLE` register, as described in the section [“601 to 699, Error Summaries” on page 102](#).

Msg#	Bit in status register	Message	Error or Warning	More Information
401	0	RPP Tripped	W	(not currently in use)
403	1	Source Unleveled	W	
405	2	Source LO Unleveled	E	(not currently in use)
407	3	LO Unleveled	E	(not currently in use)
409	4	unused		
411	5	unused		
413	6	unused		
415	7	unused		

Msg#	Bit in status register	Message	Error or Warning	More Information
417	8	unused		
419	9	unused		
421	10	unused		
423	11	unused		
425	12	unused		
427	13	unused		
429	14	unused		

501 to 599, Frequency

This series of messages corresponds to the bits in the `STATUS:QUESTIONABLE:FREQUENCY` register (see [“X-Series Status Register System” on page 109](#)). The second column in the table shows the corresponding bit in that register.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the number plus 1000 is generated. These error numbers can be viewed in the Show Errors screen, along with the DETECTED and CLEARED indicators.

For example, message 503 indicates a Frequency Reference Unlocked condition has been detected, message 1503 indicates that failure has been cleared.

This register is summarized as bit 5 of the `STATUS:QUESTIONABLE` register, as described in the section [“601 to 699, Error Summaries” on page 102](#).

Msg#	Bit in status register	Message; Description	Error or Warning	More Information
501	0	Source Synth Unlocked	E	
503	1	Frequency Reference Unlocked	E	
505	2	2 nd LO Unlocked	E	
507	3	unused		
509	4	LO Unlocked	E	
511	5	unused		
513	6	IF Synthesizer Unlocked	E	

Msg#	Bit in status register	Message; Description	Error or Warning	More Information
515	7	Calibration Oscillator Unlocked	E	
517	8	unused		
519	9	Demodulation	E	
521	10	Ref missing or out of range	E	
521	10	Ref missing or out of range; External	E	The external frequency reference signal is missing or is not within the proper amplitude range. In the PSA, this error was reported as error 622
521	10	Ref missing or out of range; Pulse	E	The pulse reference signal is missing or is not within the proper amplitude range.
523	11	unused		
525	12	unused		
527	13	unused		
529	14	unused		

601 to 699, Error Summaries

This series of messages corresponds to the bits in the `STATUS:QUESTIONABLE` register (see “[X-Series Status Register System](#)” on page 109), read with a `STATUS:QUESTIONABLE?` event query or a `STATUS:QUESTIONABLE:CONDITION?` query.

The second column in the table shows the corresponding bit in the status register. These bits do not have any corresponding error messages, although error numbers have been reserved for them as seen in the `Msg#` column; they are status bits only.

The bits in the `STATUS:QUESTIONABLE` register are “summary bits” for registers at a lower level. Note that these summary bits summarize the state and history of the event registers at the lower level. This is true even for bits in the `STATUS:QUESTIONABLE` condition register. This means that:

- The summary bits read by the `STATUS:QUESTIONABLE:CONDITION?` query are true if any event bits are set in any of the `:QUESTIONABLE` sub-registers `:POWER`, `:TEMPERATURE`, `:FREQUENCY`, `:CALIBRATION` or `:INTEGRITY`.

Instrument Messages
Condition Messages

- The summary bits read by the `STATUS:QUESTIONABLE?` event query are true if any event bit has undergone a false-to-true transition with the PTRansition filter set, or a true-to-false transition with the NTRansition filter set, in any of the :QUESTIONABLE sub-registers :POWER, :TEMPERATURE, FREQUENCY, CALIBRATION or :INTEGRITY.

Thus, the summary bits **cannot** be used to determine the current state of a lower level condition bit; only the state and history of the lower level event bits.

Msg#	Bit in status register	Message	Error or Warning	More Information
601	0	unused		
603	1	unused		
605	2	unused		
607	3	Power	status bit only	This bit is the summary bit for the STATUS:QUESTIONABLE:POWER sub-register.
609	4	Temperature	status bit only	This bit is the summary bit for the STATUS:QUESTIONABLE:TEMPERATURE sub-register.
611	5	Frequency	status bit only	This bit is the summary bit for the STATUS:QUESTIONABLE:FREQUENCY sub-register.
613	6	unused		
615	7	unused		
617	8	Calibration	status bit only	This bit is the summary bit for the STATUS:QUESTIONABLE:CALIBRATION sub-register.
619	9	Integrity	status bit only	This bit is the summary bit for the STATUS:QUESTIONABLE:INTEGRITY sub-register.
621	10	unused		
623	11	unused		
625	12	unused		
627	13	unused		
629	14	unused		

701 to 799, Operation

This series of messages corresponds to the bits in the `STATUS:OPERation` register (see “X-Series Status Register System” on page 109), which can be read with a `STATUS:OPERation?` event query or a `STATUS:OPERation:CONDition?` query.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the number plus 1000 is generated.

For example, message 721 indicates that the DC Coupled condition has been detected; message 1721 indicates that condition has been cleared.

Unless otherwise noted in the **Error or Warning** column below, these are status bits only, with no corresponding error message or number

Msg#	Bit in status register	Message	Error or Warning	More Information
701	0	Calibrating	status bit only	
703	1	Settling	status bit only	
705	2	unused		
707	3	Sweeping	status bit only	
709	4	Measuring	status bit only	
711	5	Waiting for Trigger	status bit only	
713	6	Waiting for Arm	status bit only	
715	7	unused		
717	8	Paused	status bit only	
719	9	Source Sweeping	status bit only	The “Source Sweeping” bit is used to indicate various conditions, depending on the Mode: List Sequencer Mode: Used to indicate that the sequencer is running EMI Receiver Mode: Used to indicate that scan results are available from the Frequency Scan measurement
721	10	DC Coupled	W	
723	11	unused		
725	12	Source Waiting for Trigger	status bit only	
727	13	unused		

Msg#	Bit in status register	Message	Error or Warning	More Information
729	14	unused		

801 to 899, Temperature

This series of messages corresponds to the bits in the `STATUS:QUESTIONABLE:TEMPERATURE` register (see [“X-Series Status Register System” on page 109](#)). The second column in the table shows the corresponding bit in that register.

An event with the number shown in the table means the condition has been detected. When the condition is cleared, an event with the number plus 1000 is generated. These error numbers can be viewed in the Show Errors screen, along with the DETECTED and CLEARED indicators.

For example, message 801 indicates that the Ref Osc Oven Cold condition has been detected; message 1801 indicates that condition has been cleared.

This register is summarized as bit 4 of the `STATUS:QUESTIONABLE` register, as described in the section [“601 to 699, Error Summaries” on page 102](#).

Msg#	Bit in status register	Message	Error or Warning	More Information
801	0	Reference Oscillator Oven Cold	W	(not currently in use)
803	1	Over temperature: let cool and reboot	E	The internal temperature of the instrument exceeds operating levels. The LO or the IF has signaled an overtemperature condition. Ensure proper airflow and reboot the instrument. See the Windows Event Log under SA for details.
805	2	Over current: reboot	E	The IF has signaled an over current condition. Reboot the instrument. See the Windows Event Log under SA for details.
807	3	unused		
809	4	unused		
811	5	unused		
813	6	unused		
815	7	unused		

Instrument Messages
Condition Messages

Msg#	Bit in status register	Message	Error or Warning	More Information
817	8	unused		
819	9	unused		
821	10	unused		
823	11	unused		
825	12	unused		
827	13	unused		
829	14	unused		

3 Status Register System & SCPI STATus Subsystem

Where to find Detailed Information

Detailed information about the Status Register System of X-Series instruments, including associated SCPI commands, can be found in the "Programming the Analyzer" section of any of the following documents:

- a. The online Help for any Measurement Application of any X-Series instrument,
- b. For A-Series instruments, the **X-Series User's & Programmer's Reference** manual for any Measurement Application of any X-Series instrument.

Status Register System Overview

Here is a graphical overview of the X-Series Status Register system (split into two sections for readability):

- [Figure 3-1 on page 109](#)
- [Figure 3-2 on page 110](#)

Figure 3-1 X-Series Status Register System





Figure 3-2 X-Series Status Register System (Continued)



A: References

Documents & Web Sites

- 1999 SCPI Syntax & Style Standard**

Section 21.8 defines the :`ERROR` Subsystem and standard error messages.

May be downloaded in Acrobat (PDF) format from:

<http://www.ivifoundation.org/docs/scpi-99.pdf>
- IEEE Standard 488.2-1992**

IEEE Standard Codes, Formats, Protocols, and Common Commands for Use With IEEE Std 488.1-1987, IEEE Standard Digital Interface for Programmable Instrumentation

May be downloaded in Acrobat (PDF) format from:

ieeexplore.ieee.org/iel1/2839/5581/00213762.pdf?arnumber=213762
- X-Series User's & Programmer's Reference**

For A-Series instruments, there is one such manual for each X-Series Measurement Application (Mode).

You can download any User's & Programmers Reference in PDF format from the Keysight web site. For example, the manual for the Signal Analyzer Mode (in A-Series instruments) may be downloaded from:

<http://literature.cdn.keysight.com/litweb/pdf/N9060-90027.pdf>



This information is subject to change without notice.

© Keysight Technologies 2008-2016

Edition 3, September 2016

N9020-90095

www.keysight.com